

COMBAT RATION NETWORK FOR TECHNOLOGY IMPLEMENTATION

Retort Upgrading for Surge

Final Technical Report STP#2008

Results and Accomplishments (May 2002 – December 2008)

Report No: FTR 210

CDRL Sequence: A003

November 2008

CORANET CONTRACT NO. SPO103-02-D-0024

Sponsored by:
DEFENSE LOGISTICS AGENCY
8725 John J. Kingman Rd.
Fort Belvoir, VA 22060-6221

Contractor:
Rutgers, The State University of New Jersey
School of Environmental and Biological Science
THE CENTER FOR ADVANCED FOOD TECHNOLOGY
120 New England Avenue
Piscataway NJ 08854

Principal Investigator:
Henderikus B Bruins

TEL: 732-445-6130
FAX: 732-445-6145

REPORT DOCUMENTATION PAGE					<i>Form Approved OMB No. 0704-0188</i>	
The public reporting burden for this collection of information is estimated to average 1 hour per response, including the time for reviewing instructions, searching existing data sources, gathering and maintaining the data needed, and completing and reviewing the collection of information. Send comments regarding this burden estimate or any other aspect of this collection of information, including suggestions for reducing the burden, to Department of Defense, Washington Headquarters Services, Directorate for Information Operations and Reports (0704-0188), 1215 Jefferson Davis Highway, Suite 1204, Arlington, VA 22202-4302. Respondents should be aware that notwithstanding any other provision of law, no person shall be subject to any penalty for failing to comply with a collection of information if it does not display a currently valid OMB control number.						
PLEASE DO NOT RETURN YOUR FORM TO THE ABOVE ADDRESS.						
1. REPORT DATE (DD-MM-YYYY) August 2008		2. REPORT TYPE Final		3. DATES COVERED (From - To) August 2002- December 2008		
4. TITLE AND SUBTITLE Retort Upgrading for Surge				5a. CONTRACT NUMBER SP0103-02-D-0024 / 0004		
				5b. GRANT NUMBER		
				5c. PROGRAM ELEMENT NUMBER		
6. AUTHOR(S) Henderikus B. Bruins				5d. PROJECT NUMBER STP # 2008		
				5e. TASK NUMBER		
				5f. WORK UNIT NUMBER A003		
7. PERFORMING ORGANIZATION NAME(S) AND ADDRESS(ES) Rutgers, The State University of New Jersey The Center for Advanced Food Technology School of Environmatal and Biological Sciences New Brunswick, NJ 08903				8. PERFORMING ORGANIZATION REPORT NUMBER FTR 210		
9. SPONSORING/MONITORING AGENCY NAME(S) AND ADDRESS(ES) Defense Logistics Agency 8725 John J. Kingsman Rd Fort Belvoir, VA 22060-6221				10. SPONSOR/MONITOR'S ACRONYM(S)		
				11. SPONSOR/MONITOR'S REPORT NUMBER(S)		
12. DISTRIBUTION/AVAILABILITY STATEMENT Public Availability						
13. SUPPLEMENTARY NOTES						
14. ABSTRACT Four GFE Stock 1100 retort control systems were upgraded and validated for deployed at a ration producer. Various control systems were compared and evaluated. An important decision criterion was commercial off the shelf hardware and software. The control systems application needed to comply with FDA's 21 CFR Part 11 "Rule for Electronic Records and Electronic Signatures", and be able to support both a stand alone environment and a client-server environment, where multiple retort control systems can be managed from a single location. The control system that was selected was marketed by Stock America Inc, the vendor of the retort equipment. Their control system complied with all of our criteria.						
15. SUBJECT TERMS Retort, Control System, Stock, GFE						
16. SECURITY CLASSIFICATION OF:			17. LIMITATION OF ABSTRACT Unclassified	18. NUMBER OF PAGES	19a. NAME OF RESPONSIBLE PERSON Henderikus B. Bruins	
a. REPORT	b. ABSTRACT	c. THIS PAGE			19b. TELEPHONE NUMBER (Include area code) 732-445-6130	
Unclassified	Unclassified	Unclassified				

Abstract

Four GFE Stock 1100 retort control systems were upgraded and validated for deployment to a ration producer. Various control systems were compared and evaluated. An important decision criterion was commercial off the shelf hardware and software. The control systems application needed to comply with FDA's 21 CFR Part 11 "Rule for Electronic Records and Electronic Signatures", and be able to support both a stand alone environment and a client-server environment, where multiple retort control systems can be managed from a single location. We selected the control system that was marketed by Stock America, the vendor of the retort equipment. Their control system complied with all of our criteria.

At the end of the project, all four upgraded retorts were deployed and are currently running in a client server configuration.

Index

1	Results and Accomplishments.....	5
1.1	Introduction and Background.....	5
1.2	Objectives.....	5
1.3	Results and Conclusions	5
2	Program Management	6
3	Short Term Project Activities	6
3.1	Stock 1100 LogTec Retorts.....	6
3.1.1	Retort Inventory.....	6
3.1.2	Retort Installation	7
3.1.3	Retort Upgrade	7
3.1.4	Retort Startup and Validation	7
3.1.5	Retort Storage and Maintenance.....	7
3.1.6	Retort Shipment.....	8
3.1.7	Retort and Rack Inventory	8
3.1.8	Licensed Software	8
3.1.9	Technology Support	9
4	Appendix:	11

1 Results and Accomplishments

1.1 Introduction and Background

Under a DLA Mantech project for combat rations (CORANET), Rutgers Food Manufacturing Technology Facility (FMTF) has assembled, upgraded, and validated eight Stock Rotomat Model 1100 retorts and three Stock Rotomat Model 1300 retorts. Four more Stock 1100 retorts were shipped to Rutgers FMT Facility for inspection on August 15, 2001. One retort was assembled and installed in the retort room, while the other three retorts were assembled and stored in the warehouse. Rutgers inspected all four retorts and determined their deficiencies. To upgrade these retorts to a state of readiness, Rutgers identified all required improvements that needed to be made.

It was determined that the LOGTEC control systems used in these last four retorts can no longer be supported due to lack of available electronic components. Upgrading the control system, in order to support these retorts during production, was deemed an essential requirement to assure the long term operational status of the retorts.

In support of DSCP's Enduring Justice combat ration supply requirements, two of these retorts were shipped out for immediate deployment on September 24, 2001 to SOPAKCO Texas. The two other retorts remained at the FMT facility and this project would upgrade these retorts and make them operational.

After the upgrade of the first two retort would be completed, an exchange would take place and the two remaining retorts with the out dated control system would be sent back to the FMT facility for their upgrade and validation.

DSCP intends to make all retort equipment available to ration producers as Government Furnished Equipment (GFE) for limited peacetime use, but mainly to be available during surge.

1.2 Objectives

- Manage and maintain Stock 1100 retorts that are located at the CORANET Demonstration Facility in Piscataway, NJ, and others that may be received. Maintenance will be in accordance with the Maintenance and Readiness Plan developed during STP#1011.
- Upgrade four Stock 1100 retorts from LogTec control systems to ICON 2000 version 4 control systems and validate their operational status.

1.3 Results and Conclusions

The final four GFE Stock 1100 retorts were upgraded and validated for deployed to a ration producer. We compared a various control systems upgrades. A facilitate easy up keep, it was decided to install commercial off the shelf hardware and software and to require that the software application could run in both a stand alone environment and in a client-server environment. The control system selected from Stock America Inc. complied with these requirements and complied with FDA's 21 CFR Part 11 "Rule for Electronic Records and Electronic Signatures". All four retorts were deployed and are currently running in a client server configuration.

One GFE retort, with an old style control system (ICON 2000 version2), remains at the CORANET Demo facility in support of the CORANET activities. This retort is being maintained in a state of readiness and can be deployed on a moment notice.

2 Program Management

The project was awarded on May 7, 2002 under SPO103-02-D-0024, Delivery Order 0004 with a partial obligation of \$32,687.00 of the total requested amount of \$127,687.00. The initial performance period for this delivery order was set at 12 month (May 6, 2003). The initial contract award was to upgrade the two Stock Retorts with LogTec controllers located at the FMT facility.

The following modifications were issued:

July 30, 2002	0004/02	Increased funding, increasing total obligation to 53,088.85
August 1, 2002	0004/03	Increased funding, increasing total obligation to 139,659.85
August 20, 2002	0004/04	Correction the total obligation to 139,298.85
May 6, 2003	0004/05	No cost extension through to December 31, 2003
May 21, 2003	0004/06	Increased funding, increasing total obligation to \$146,720.85 to support additional maintenance and upgrade cost that will be incurred
Sept 30, 2003	0004/07	Upgrade of two additional retorts, extending period of performance to November 30 th 2004, increased funding, increasing total obligation to \$264,533.11 which was a partial incremental obligation
Feb 11, 2004	0004/08	Increased funding, increasing total obligation to \$301,327.85, the total amount that was requested
Feb 18, 2004	0004/09	Correction to block 14 information
Nov 29, 2004	0004/10	No cost extension to May 30, 2005
May 17, 2004	0004/11	No cost extension to November 30, 2005
Nov 29, 2005	0004/12	No cost extension to June 30, 2006
June 30, 2006	0004/13	No cost extension to June 30, 2007
Sep 16, 2006	0004/14	Increased funding, increasing total obligation to \$311,327.85 to fund continued preventative maintenance of the GFE retort as well as to ensure system readiness
June 20, 2007	0004/15	No cost extension to June 30 2008
June 10, 2008	0004/16	No cost extension to December 31, 2008

3 Short Term Project Activities

3.1 Retort Upgrades

3.1.1 Retort Inventory

At the beginning of this project (May 2002) the FMT Facility had the following retorts in Inventory:

- Stock 1100, ICON 2000 version 2, serial number 64026
- Stock 1100, ICON 2000 version 2, serial number 64027
- Stock 1100, LOGTEC, serial number 39883
- Stock 1100, LOGTEC, serial number 39892

3.1.2 Retort Evaluation

The Government acquired four Stock model 1100 retorts with LogTec control system (serial numbers 39882, 39883, 39992 and 39993). These retorts were initially stored at Vanee Foods in Chicago but shipped to the CORANET Demo Facility on 8/15/01 for the purpose to install and inspect their readiness. The retorts were purchased without a required host computer system and thus not operational unless the manufacturer integrated these retort into their own LogTec host system. Two of the retorts (#39882 & #39993) were temporarily shipped to SOPAKCO Texas on September 24, 2001 in support of Enduring Justice. SOPAKCO Texas uses LogTec controllers on their own retorts and was therefore able to integrate the two GFE retorts and make them operational.

The two other retorts remained at the FMT facility and were evaluated for their readiness under a previous project STP#2011. It was determined that the current LogTec control system was out dated and not longer

supported. Recommendations were made that the control systems should use Commercial off the Shelf Hardware and Software and that each retort should be configurable to run in a stand alone mode without required host computer, giving the equipment more flexibility as GFE equipment.

3.1.3 Retort Installation

During this project retorts that needed to be used, upgraded and/or validated, were moved into the retort room and hooked up to the essential utilities. Once the upgrade and validation was completed, the retorts were disconnected, stored and readied for immediate deployment.

3.1.4 Control System Upgrade

On August 22, 2002 Stock America submitted their proposal 2520A-02 (Appendix I), detailing the cost per unit control conversion/upgrade to their ICON-SE control system, a system that has the necessary components and features, functions and tools to operate the retorts and allowing manufacturers to implement electronic record keeping solutions that meet the requirements of FDA's 21 CFR Part 11 "Rule for Electronic Records and Electronic Signatures". The new control system gave the ration producer the flexibility to run it in either a stand-alone mode or in a network configuration in which one host computer manages various retorts. Two retorts with the serial #39883 & #39992 were upgraded under this proposal

On October 2, 2003 Stock America submitted their proposal 2617-03 (Appendix II) for the conversion of two additional Stock 1100 Retorts (serial #39882 & 39993) from the existing Log-Tec controls to same Stock America's ICON-SE Control System as used in the previous two systems.

3.1.5 Retort Startup and Validation

The first two retorts (serial #39883 & 39992) were upgraded by Stock America starting January, 2003 with the replacement of the control system. Once the new control systems were in place, the retorts were hooked up to utilities and checked out for functionality. Final validation of both retorts was completed by March 2003, both in a stand-alone and host mode configuration.

The second set of retorts (serial #39882 & 39993) was upgraded by Stock America starting December 2003 with the replacement of the control system. Once the new control systems were in place, the retorts were hooked up to utilities and checked out for functionality. Final validation of both retorts was completed by March 2004, both in a stand-alone and host mode configuration.

An electronic version of the control system manual is included as Appendix III

3.1.6 Retort Storage and Maintenance

After completion of the upgrade and validation, the retorts were drained from all water and readied for shipment. The following retorts were stored and maintained before they were shipped to SOPAKCO.

- Stock 1100, ICON 2000 version 2, serial number 64026
- Stock 1100, LOGTEC, serial number 39883
- Stock 1100, LOGTEC, serial number 39892

Retort #64027 has been maintained in operational mode, and used to support the needs of the CORANET program. The retort has been used on a monthly basis to check basic functionality of pumps, valves and control system. The following maintenance issues were resolved:

- August 2003: Computer hard disk crashed and was replaced.
- October 2003: Two I/P converter on steam valve and storage vessel pressure control valve malfunctioned and were replaced.
- December 2003: CMOS Battery in PC failed and was replaced.
- April 2004: Cold water valve malfunctioned, cams and relay adjusted and unit was cleaned.
- July 2004: a Burkert Solenoid valve shorted out and was replaced.

- October 2004: The problem with the cold water valve did reoccur. A replacement motor was ordered and old motor was sent out for overhaul
- January 2005: Battery backup failure in PLC, Ladder Logic program was lost and needed to be reloaded after a new battery was installed.
- April 2005: Flapper valve did not open up fully, resulting in poor temperature distribution, water level control and temperature control. The drive motor was taken apart and realigned.
- October 2005: A problem was discovered during the heating phase of the storage drum. Upon inspection, steam sparger had broken off inside the vessel. Corroded piping and sparger were repaired/replaced.
- January 2006: A safety solenoid valve malfunctioned. This valve was replaced.
- April 2006: A problem was encountered with the UPS, causing the control system to suddenly shut down. The unit was replaced.
- August 2006: System battery of operator interface failed and was replaced causing loss of system configuration. New battery was obtained and system was reinitialized.
- September 2006: The motor on the Drain Valve failed to open and was sent to Stock America for repair.
- December 2007: A data corruption error occurred with the hard disk drive, causing the system to shutdown. A repair utility program was used to resolve this issue. A new hard disk drive might need to be installed if the problem reoccurs.
- February 2008: The Vent Valve malfunctioned. Motor and Valve were removed and overhauled by Stock America.
- February 2008: The battery backup of the PLC failed in February, causing the loss of the PLC program. New Battery was installed and the program was reloaded and retort re-validated
- March 2008: CMOS Battery in PC failed and was replaced.

3.1.7 Retort Shipment

Detailed information on the items shipped can be found in appendix IV. A summary is given below.

- On July 17 2002, one retort (serial number #64026) was shipped to SOPAKCO Texas, a system with an ICON 2000 version 2 control system. Included in this shipment were 96 retort racks (7333A) and 5 top plates (7333A)
- On April 15, 2003, two upgraded Stock 1100 retorts (serial #39883 & 39992) were shipped to SOPAKCO Bennettsville SC, included in this shipment was 16 baskets, 16 dollies
- On 11/19/03, two retorts #39882 and #39993 were received from SOPAKCO Mullins to the CAFT FMT Facility
- On April 6, 2004, two additional upgraded Stock 1100 retorts (serial #39882 & 39993), old LogTec Interfaces and a Callahan Seamer which was located at the FMT facility were shipped to SOPAKCO in Bennettsville SC.

3.1.8 Retort Inventory

On July 30th 2008 the following inventory of retorts remained at the Rutgers FMT facility

- Stock 1100, ICON 2000 version 2, serial number 64027

3.1.9 Licensed Software

The following licensed software was installed on the four upgraded retorts, including one host system that can manage all four retorts:

Host Computer:

- ❑ Microsoft 2000 Server 5.00.2195 SP2, key VRPQX-CMD48-WB74X-2YKWQ-MXHW8, License# 51876-OEM-0005045-20563
- ❑ Microsoft 2000 Professional BHY7Q-PDDTX-HJWW7-06CX9-KJMW8 (second label on PC???)
- ❑ RSView SE Client Rev 2.10.00 ser # 2524000449 9701VWSCWAENE
- ❑ RSView SE Server 100 Rev 2.00.01 ser# 2527000280 9701VWSS100AENE

- ❑ RSSQL Standard 5000 Rev 5.00.00 ser# 2562000121 9356STD2350
- ❑ RSMACC Ver 1.01.00 ser# 2418000104, 9515-MACCCD-10.16.02
(not installed)
- ❑ Microsoft Office 2000 SBE, lic#: 54188-OEM-1792691-89839
- ❑ Microsoft SQL Server 2000 Standard SP2 BHD87-9R9XR-97KFF-PTWVP-K7P3M

Retort 882 (PC#M930100184)

Microsoft 2000 Professional, Version 5.00 2195, SP2, key THJRC-MPBJV-VWP4W-4PTJY-298JM, License #

- ❑ View SE Client Rev 3.00.01 ser # 2524002405 , cat#: 9701VWSCWAENE
- ❑ RSView SE Server 25 Rev 3.00.01 ser# 2526000889, cat#: 9701VWSS025AENE
- ❑ RSSQL Standard 1500 Rev 6.00.02 ser# 1126000556, cat#: 9356STD2300
- ❑ Microsoft Office XP SBE, VDPTM-7HF9H-WR64P-R7FHR-TVT63
- ❑ Microsoft SQL Server 2000 Personal Edition, SP-3a B4X86-JGK67-FTFQJ-VKRKG-DXMMT

Retort 993 (PC#M930100190)

- ❑ Microsoft 2000 Professional, Version 5.00 2195, SP2, key FYP96-KHDWT-HB8J9-MDBJX-Y2DJ, License # 51873-OEM-0011577-07407
- ❑ RSView SE Client Rev 3.00.01 ser # 2524002406, cat#: 9701VWSCWAENE
- ❑ RSView SE Server 25 Rev 3.00.01 ser# 2526000890, cat#: 9701VWSS025AENE
- ❑ RSSQL Standard 1500 Rev 6.00.02 ser# 1126000557, cat# 9356STD2300
- ❑ Microsoft Office XP SBE, GTGT6-VPQGC-77326-37FKW-DGX2M
- ❑ Microsoft SQL Server 2000 Personal Edition, SP-3a GHXDG=H74RV-JKJX4-9HTKH-QH6QY

Retort 883

- ❑ Microsoft 2000 Professional, Version 5.00 2195 SP 3, key FC9FD-9DRGV-GX4X7-FJPD8-VRMQJ, License # 51837-OEM-0009955-23195
- ❑ RSView SE Client Rev 2.10.00 ser # 2524001131 , 9701VWSCWAENE
- ❑ RSView SE Server 25 Rev 2.00.01 ser# 2526000236, 9701VWSS025AENE
- ❑ RSSQL Professional 1500 Rev 5.00.00 ser# 1131000765,
- ❑ Microsoft Office XP 2000 SBE, DWMD4-4YYHR-BDRGJ-6J2WF-TCD2J
- ❑ Microsoft SQL Server 2000 Personal Edition, F7769-PCT2R-9MP4C-2HCWG-DQJBT
- ❑ Microsoft Internet Explorer, Version 6.0.2800.1106, SP 1

Retort 992

- ❑ Microsoft 2000 Professional, Version 5.00 2195 SP 3, key MHM4D-HPJK2-KVXMB-HQQVY-8MYQG, License # 51837-OEM-0009955-23194
- ❑ RSView SE Client Rev 2.10.00 ser # 2524000448, 9701VWSCWAENE
- ❑ RSView SE Server 25 Rev 2.00.01 ser# 2526000235, 9701VWSS025AENE
- ❑ RSSQL Professional 1500 Rev 5.00.00 ser# 1131000766, 9356PRO2300
- ❑ Microsoft Office XP 2000 SBE, QT343-8H63D-CGMMQ-2VDR4-8KXF6
- ❑ Microsoft SQL Server 2000 Personal Edition, QXC83-XVKDY-KCPH3-K4YRF-FCX73
- ❑ Microsoft Internet Explorer, Version 6.0.2800.1106, SP 1

3.1.10 Technology Support

After completing the upgrades of the final four GFE retorts and giving initial support to SOPAKCO in getting the upgraded GFE retorts installed and operational, we continued to support the GFE retort equipment by making our expertise available to DSCP and the ration industry.

- **October 2004:** The host computer with related software was send to Stock America beginning of July for an upgrade. Stock America completed the software development and installation by October 14, 2004 after which the host computer was send to SOPAKCO. SOPAKCO used the host system to run all four retorts in a client server mode.
- **September 2006:** Ameriquel personnel visited the Demo facility to become familiar with the ICON control system in preparation to DSCP planned relocation of three Stock 1300 GFE retorts

to Ameriqua. Additional technology transfer and assistance was given towards the end of the month once the retorts had been received and identification of a few parts was required.

- **October 2006:** Technology transfer and assistance was given to Ameriqua during the installation and start-up of the GFE-Stock-1300 retorts. List of parts and software backups were provided as well as passwords for both the OI and PLC program.

4 Appendix:

Appendix I: Stock America Proposal #2520A-02

Appendix II: Stock America Proposal # 2617-03

Appendix III: ICON-SE Operating Manual

Appendix IV: Retort Shipment Information

Appendix I: Stock America Proposal #2520A-02

**STOCK AMERICA INC.
STERILIZATION SYSTEMS DIVISION**

1935 Evans Road
Cary, NC 27513

PROPOSAL # 2520A-02

Prepared by T. Schurr

PH. (919) 678-8201
FX. (919) 678-8204

**TO: RUTGERS UNIVERSITY
120 NEW ENGLAND AVENUE
PISCATAWAY, NJ 08854**

DATE: AUGUST 22, 2002

REFERENCE: STOCK CONTROL CONVERSION

ATTENTION: RIEKS BRUINS

We are pleased to provide the following firm quotation for the conversion of 2 (two) Stock Retorts to our ICON Control System. This quote is valid for 45 days from the date of issue.

Stock Retort Control Upgrade – ICON Intelligent Control Network

1. Hardware conversion including:
 - a. Removal of existing Logic Controller and Log-Tec Interface
 - b. Modification or replacement of front panel door with appropriate cutouts, switches and legend plates
 - c. Substitution of Allen-Bradley SLC500 5/05 processor and Windows 2000 Industrial PC Operator Interface
 - d. Retention of all transmitters, transducers, sensors, switches and level sensors unless itemized below.
 - i. New Minco temperature transmitters for SV and PV control
 - e. Retention of motor control components, I/P transducers, relays and contacts.
 - f. Add UPS – uninterruptible power supply/battery back up system
 - g. Shielded analog cable for all analog inputs
 - h. Installation, wiring, start up and operational validation
 - i. Conduit and utility services to machine by customer– termination and validation by Stock
2. Software conversion, including:
 - a. Implementation of Stock America developed and maintained ICON Automated Batch Retort software code for both Operator Interface and SLC500 processor
 - b. Installation, validation and training
 - c. ICON user manuals
3. On-site Time and Expenses, including;
 - a. All travel and living expenses for service and process validation personnel
 - b. Temperature Distribution and Heat Penetration testing is not included.

PRICE, PER UNIT

... \$ 25,495.00

4. ICON Host/Supervisory System, including;
 - a. All PC hardware, software and printer
 - b. Capacity for 2 retorts (Maximum of 10 with license upgrade)
 - c. ICON Automated Batch Retort software, consisting of:
 - i. Recipe Management, incl. Embedded Ball Formula Calculation

STOCK AMERICA INC.
STERILIZATION SYSTEMS DIVISION

1935 Evans Road
Cary, NC 27513

PROPOSAL # 2520A-02

Prepared by T. Schurr

PH. (919) 678-8201

FX. (919) 678-8204

- ii. Process Data Logging with Retort Status Screen and FDA accepted batch report printouts
- iii. Tools to view and re-print past batch reports
- iv. Security Administration
- d. Compliance with 21 CFR Part 11 electronic record keeping requirements
- e. Process Data is stored in an ODBC compliant database.

PRICE, PER HOST SYSTEM

... \$ 11,875.00

5. Change Management Software

- a. Manufacturers who seek to achieve compliance with the FDA's 21 CFR Part 11 Rule for Electronic Records and Electronic Signatures must implement Best Practices, Corporate Policies, or Standard Operating Procedures (SOPs) to enforce security measures and ensure the safeguard of electronic record and signature information. The manufacturer must also institute qualified training to individuals responsible for these systems.
- b. The ICON Automated Batch Retort System is comprised of components that include the necessary features, functions and tools to assist in allowing manufacturers to implement electronic record keeping solutions that meet the requirements of the FDA's 21 CFR Part 11 Rule for Electronic Records and Electronic Signatures.
- c. Change Management Software provides security, version control, audit trails, central storage and automated backup and compare.

PRICE, for CHANGE MANAGEMENT SYSTEM

... \$ 5,000.00

6. Optional Upgrades, per unit additional pricing

- | | | | |
|---|-----|----|----------|
| a. ES Mode piping and ES Mode valves, inc. installation | ... | \$ | 3,180.00 |
| b. Barksdale Steam Pressure Switch – install by customer | ... | \$ | 108.00 |
| c. VFD Conversions, 5 hp, inc. polychain conversion and installation | ... | \$ | 2,540.00 |
| d. Analog Drain Valve, for water level control, w/ DIN flanges, inc. wiring, configuration and validation | ... | \$ | 2,585.00 |
| e. Additional rotor position proximity switch, configured and wired | ... | \$ | 140.00 |
| f. Temperature Distribution verification, per unit, including all travel and Living expenses (based on 2 trips for 4 retorts) | ... | \$ | 2,150.00 |

7. Conversion from ICON v.4 Distributed Server-Client to "Stand-alone", including

- | | | | |
|--|-----|----|----------|
| a. Upgrade R.A.C. 6181 to Server Version (Pentium III, 256 MB) | ... | \$ | 807.00 |
| b. Add MS Office 2000 Pro | ... | \$ | 408.00 |
| c. Add One (1) RSView SE Server (25 Display) | ... | \$ | 2,800.00 |
| d. SAI Engineering Support | ... | \$ | 1,000.00 |

Total, Without Options

\$ 5,015.00

- | | | | |
|-----------------------------|-----|----|----------|
| e. Optional SQL Server 2000 | ... | \$ | 1,607.00 |
| f. Optional Crystal Reports | ... | \$ | 552.00 |

**STOCK AMERICA INC.
STERILIZATION SYSTEMS DIVISION**

1935 Evans Road
Cary, NC 27513

PROPOSAL # 2520A-02

Prepared by T. Schurr

PH. (919) 678-8201
FX. (919) 678-8204

Assumptions:

1. Original components, including I/P transducers, pressure switches, level sensors, motor starters, relays and other components are retained unless specifically listed. ***If necessary, Stock will repair, replace or upgrade existing retort components, valves or field devices at additional cost.***
2. The ICON Automated Batch Retort System is FDA accepted and U.S.D.A. approved and year 2000 compliant. Compliance with 21 CFR Part 11 requires implementing the Change Management software solution in conjunction with the ICON system. Validation for 21 CFR Part 11 compliance is available at extra cost.
3. Additional ICON Host Systems are available for \$10,950.00.
4. Additional Change Management systems are available for \$11,675.00
5. Additional Operator Interface systems are available for \$9,875.00
6. Additional SLC500 systems are available for \$8,475.00

Contributions:

This proposal contains contributions offered by Stock America to offer a price effective control solution to Rutgers University. Below is a table that details the amount of these contributions Stock America has offered within this proposal.

Price Reduction for Project Engineering and Software Development	Savings of \$8,800.00
Price reduction for ICON Automated Batch Retort System	Savings of \$1,475.00
Price reduction for Operator Interface	Savings of \$4,800.00 each
Price reduction for Change Management Software	Savings of \$6,675.00

Delivery: Approximately 8 - 10 weeks after receipt of down payment

Payment Terms: 50% down-payment with firm order
40% Upon Shipment
10% After Start Up, Not to exceed 60 days after shipment

Shipping: F.O.B. Cary, NC. Shipping costs will be pre-paid and added to the final invoice.

Appendix II: Stock America Proposal # 2617-03

**STOCK AMERICA INC.
STERILIZATION SYSTEMS DIVISION**

1935 Evans Road
Cary, NC 27513

PROPOSAL # 2617-03

Prepared by T. Schurr

PH. (919) 678-8201
FX. (919) 678-8204

**TO: RUTGERS UNIVERSITY
120 NEW ENGLAND AVENUE
PISCATAWAY, NJ 08854**

DATE: OCTOBER 2, 2003

REFERENCE: STOCK CONTROL CONVERSION

ATTENTION: RIEKS BRUINS

We are pleased to provide the following proposal for the conversion of 2 (two) Stock 1100 Retorts currently located at SOPAKCO in Mullins, SC from existing Log-Tec controls to Stock America's ICON^{SE} Control System.. This quote is valid for 60 days from the date of issue.

Stock Retort Log-Tec Control Upgrade – ICON^{SE} Secure Control Network

1. Hardware conversion including:
 - a. Removal of existing Log-Tec controls
 - b. Acquisition, assembly and installation of new control back panel in existing front enclosure, including mounted relays, contacts and terminal blocks, with interconnections pre-wired
 - c. Modification of front panel door with appropriate cutouts, switches and legend plates
 - d. Allen-Bradley SLC500 5/05 processor and Windows 2000 Industrial PC Operator Interface
 - e. Retention of all transmitters, transducers, sensors, switches and level sensors unless itemized below
 - i. New Minco temperature transmitters for SV and PV control (32-302 Deg F)
 - f. Retention of motor control components, I/P transducers, relays and contacts
 - g. UPS (for Industrial PC only)
 - h. 16 AWG blue wire and shielded analog, control power transformer, DC power supply, terminal blocks, relays, fuses Etc.
 - i. Copper tubing, fittings, flex conduit Etc.
 - j. Installation, wiring, start up and operational validation
 - k. Conduit and utility services to machine by customer– termination and validation by Stock America
2. Software conversion, including:
 - a. Implementation of Stock America developed and maintained ICON^{SE} Stand-alone Automated Batch Retort software for both Operator Interface and SLC500 processor
 - b. Installation, IQ and OQ validation and training
 - c. ICON^{SE} user manual
3. On-site Time and Expenses, including;
 - a. 2 (two) weeks of time, travel and living expenses for a Stock America Service Technician
 - b. 1 (one) week of time, travel and living expenses for a Stock America Controls Engineer
 - c. ½ (one half) week of time, travel and living expenses for a Stock America Process Technologist (temperature distribution and heat penetration testing is not included)

STOCK AMERICA INC.
STERILIZATION SYSTEMS DIVISION

1935 Evans Road
Cary, NC 27513

PROPOSAL # 2617-03

Prepared by T. Schurr

PH. (919) 678-8201
FX. (919) 678-8204

PRICE, PER UNIT

○ ICON^{SE} conversion, including Client Software	...	\$	28,140.00
○ add upgrade to 'Standalone' ICON^{SE}	...	\$	5,015.00
○ add validation for Distributed Client – Server deployment	...	\$	4,100.00

4. Optional Upgrades (per Retort)

a. ES Mode valves including installation	...	\$	3,180.00
b. Barksdale steam pressure switch (installation by customer)	...	\$	95.00
c. VFD conversion including poly-chain, SLC RIO module & enclosure	...	\$	3,275.00
d. Analog Drain valve for water level control, w/ DIN flanges, including I/P transducer, wiring, configuration and validation	...	\$	2,585.00
e. Additional rotor position proximity switch, configured and wired	...	\$	75.00
f. Analog PV level transmitter and stand-pipe	...	\$	1,815.00
g. 1 (one) Manual SV temperature gage	...	\$	250.00
h. 2 (two) Ashcroft pressure transmitters	...	\$	1,065.00

Assumptions:

1. Original components, including I/P transducers, pressure switches, level sensors, motor starters, relays and other components are retained unless specifically listed. ***If necessary, Stock will repair, replace or upgrade existing retort components, valves or field devices at additional cost.***
2. The ICON Automated Batch Retort System is FDA accepted and U.S.D.A. approved and year 2000 compliant. Validation for 21 CFR Part 11 compliance is available at extra cost.
3. It is assumed that the Retorts will be brought from SOPAKCO to the CAF.T. facility in New Jersey for performing this conversion (Stock America is not responsible for transportation of the Retorts).

**STOCK AMERICA INC.
STERILIZATION SYSTEMS DIVISION**

1935 Evans Road
Cary, NC 27513

PROPOSAL # 2617-03

PH. (919) 678-8201
FX. (919) 678-8204

Prepared by T. Schurr

Contributions:

This proposal contains contributions offered by Stock America to offer a price effective control solution to Rutgers University. Below is a table that details the amount of these contributions Stock America has offered within this proposal.

Price Reduction – discount on services	Savings of \$4,025.00 (per Retort)
Price Reduction – discount on software	Savings of \$4,510.00 (per Retort)
Price Reduction – discount on hardware	Savings of \$3,375.00 (per Retort)

Delivery: To Be Determined

Payment Terms: 50% down-payment with firm order
40% upon Shipment
10% after Start-up, not to exceed 60 days after shipment

Shipping: F.O.B. Cary, NC. Shipping costs will be pre-paid and added to the final invoice

Appendix III: ICON-SE Operating Manual

OPERATIONS

MANUAL

ICON^{SE}

Table of Contents

Table of Contents	0
STOCK America Inc. Contact Information	0
SECTION 1 - GENERAL OVERVIEW	1
a. Sequence of Events – Pre-start up	1
b. Sequence of Events – Start Up	1
SECTION 2 - SYSTEM SECURITY	2
a. General	2
b. Security Levels	2
c. Managing User Accounts	3
Step 1 – Shut down ICON SE and Windows system	3
Step 2– Exit ICON SE system	3
Step 3 – Windows User Account Administration	4
Step 4 – Windows User Account Administration	5
Step 5 – Windows User Account Administration	6
Step 6 – Windows User Account Administration	7
Step 7 – Windows User Account Administration – Local Users & Groups	7
Step 8 – Windows User Account Administration – User Information	8
d. Changing Windows User Account Passwords	9
General	9
Setting Password	9
Entering Password	9
Confirming Password Change	9
d. Deleting Windows User Account	10
General	10
Deletion Warning	10
e. Managing User Accounts in RS View	11
General	11
Procedure	11
Opening Application	12
Selecting User Accounts	13
Accessing User Accounts	13
Adding User Accounts	14
Deleting User Accounts	14
Setting User Privileges	15
SECTION 3 – HOST COMPUTER	16
a. Software and Hardware Requirements	16
Before You Begin	16
Information for Stand Alone Retort Installations	16
Time and Date Management	16
Hardware Specification	16
Software Specification	16

SECTION 4 - ICON^{SE} STARTUP, SHUT DOWN & LOGIN PROCEDURES **17**

a. Utility Start - Up Procedure	17
b. Retort Power-Up Procedure	17
c. Software Start - Up Procedure	17
d. Software Reboot Procedure	17
e. Login Procedure	17

SECTION 5 - ICON^{SE} HUMAN MACHINE INTERFACE **18**

a. General Information	18
b. Interface and Input Screen Examples	18
Overview Screen (Fig. 5.1)	19
Main Menu (Fig. 5.2)	20
Keyboard (Fig. 5.3)	21
Key Pad (Fig 5.4)	21
Recipe Management Screen (Fig 5.5)	22
Step Management (Fig. 5.6)	23
Recipe Settings (Fig. 5.7)	24
Select Product Code (Fig. 5.8)	25
Set point Input (Fig. 5.9)	25
Report Generation Form – Please Select Batch ID (Fig. 5.10)	26
Login (Fig. 5.11)	26
Product Registration (Fig. 5.12)	27
Update confirmation (Fig. 5.13)	27
Custom Table Settings (Fig. 5.14)	28
String Input (Fig. 5.15)	29
Download Confirmation (Fig. 5.16)	29
Retort Screen (Fig. 5.17)	30
Start Confirmation (Fig. 5.18)	31
IT Configuration (Fig. 5.19)	31
Pause Confirmation (Fig. 5.20)	32
Remove Pause & Continue Process (Fig. 5.21)	32
Hold Confirmation (Fig. 5.22)	33
Remove Hold Confirmation (Fig. 5.23)	33
Abort Confirmation (Fig. 5.24)	34
User Input Confirmation (Fig. 5.25)	34
Alarm Summary (Fig. 5.26)	35
Operational Range of Set Points and Fields (Fig 5.27)	36
Input Validation (Fig 5.28)	37
Trending Screen (Fig 5.29)	37

SECTION 6 - RECIPE MANAGEMENT **38**

a. Loading Existing Recipes	38
Step 1 - Select Product Code	38
Step 2 - Load Product Code	38
Step 3 - Loading Completed	39
b. Clearing Displayed Recipe	40

General	40
c. Creating a New Recipe & Recipe Parameters	41
General	41
Step 1 – Add a New Recipe	41
Step 2 - Choosing a Step	42
Step 3 - Creating New or Changing Set Point Parameters - Begin	43
Step 4 - Set Point - Input	43
Step 5 - Set Point – Data Entry	44
Step 6 - Set Points – Accept or Reject	44
Step 7 - Set Points – Screen Shot Finished Recipe	45
Step 8 - Step Management	46
Step 9 – Product Registration.....	47
d. Creating Recipes from a Template	48
General	48
Step 1 - Product Code Template	48
Step 2 - New Product Code Designation.....	48
e. Updating Recipes.....	49
General	49
Step 1 - Updating of Recipe	49
Step 2 – Confirmation of Update	50
Step 3 – Finished Update	50
f. Registering Recipes	51
General	51
Step 1 - Registration of Recipe	51
Step 2 - Registration Confirmation	52
g. Downloading Recipes.....	53
General	53
Step 1 - Downloading	53
Step 2 – Download Confirmation	53
SECTION 7 - ICON^{SE} MODIFY PROCESS STEPS	54
a. Example Full Water Immersion Step Modification	54
Step 1 - Heating Storage Vessel (HSV) - Completed	54
Step 2 - Sterilization 1 (S1) - Completed	55
Step 3 - Sterilization 2 (S2) - Completed	56
Step 4 - Sterilization 3 (S3) - Completed	57
Step 5 - Cooling 1 (C1) - Completed	58
Step 6 - Cooling 2 (C2) - Completed	59
Step 7 – Drain - Completed.....	60
Step 8 - Process Table Modification – Completed.....	61
Step 9 - Update Recipe - See Section 5(e) for procedure	61
Step 10 - Register Recipe - See Section 5(f) for procedure	61
SECTION 8 - RUNNING A PROCESS	62
a. General	62
b. Example Full Water Immersion Process	62
Starting the Process.....	62

Heating Storage Vessel (HSV) \leq 212 Deg F - No Pressure Control	64
Heating Storage Vessel (HSV) \geq 212 Deg F – Pressure Control	65
Heating Storage Vessel End - Prompt for IT	66
Sterilization 1 - In Progress.....	67
Sterilization 2 - In Progress.....	68
Sterilization 3 - In Progress.....	69
Sterilization 3 - In Progress – User Inputs	70
Cool 1 - In Progress	71
Cool 2 - In Progress	72
Drain - In Progress	73
Process Pause - In Progress.....	74
Process Hold - In Progress	75
Remove Process Hold - In Progress.....	76
Trends – Viewing.....	77
General.....	77
Select Trends Option.....	77

STOCK America Inc. Contact Information

Main Office: 995 Badger Circle; Grafton, WI 53024

Phone	(262) 375 – 4100
Fax	262) 375 – 4101
E Mail	stockamerica.com

Southeastern Office: 1935 Evan RD; Cary, N.C. 27513

Phone	(919) 687 – 8201
Fax	(919) 687 – 8204
E Mail	stockamerica.com

Sales Department

Dave Polvino: 1935 Evan RD; Cary, N.C. 27513

Phone	(919) 687 – 8201
Fax	(919) 687 – 8204
E Mail	davep@stockamerica.com

Jay Cobb: 1935 Evan RD; Cary, N.C. 27513

Phone	(919) 687 – 8201
Fax	(919) 687 – 8204
E Mail	jayc@stockamerica.com

ProTecS Process Technology Services Division: Contacts

Tom Pampel: 995 Badger Circle; Grafton, WI 53024

Phone	(262) 375 – 4100
Fax	(262) 375 – 4101
Cell Phone	(262) 573 – 9576
E Mail	tomp@stockamerica.com

Rick Way: 67 Painter Ave; West Haven, CT 06516

Phone	(203) 931 – 0910
Fax	(203) 931 – 0919
Cell Phone	(203) 494 – 0087
E Mail	rickw@stockamerica.com

SECTION 1 - GENERAL OVERVIEW

a. Sequence of Events – Pre-start up

Each project involving a new retort purchase or a controls retrofit is traceable to a Technical Description, Control / Electrical Specification and Installation Qualification Document that is provided in written form by STOCK America, Inc. If there are any questions regarding installation, start up or technical detail, the Technical Description and Control Specification as well as the Installation Qualification Document should be consulted. For additional copies or questions regarding this information, please contact your STOCK America, Inc. Project Manager.

Installation assistance is available from the STOCK America, Inc. technical department in the form of utility recommendations, layout options / drawings and relevant electrical schematics as defined in the project documentation summary. Phone support is included for an agreed upon time frame at no extra charge; on-site assistance may be requested and would be quoted at prevailing service rates.

b. Sequence of Events – Start Up

After retort and control installation is complete, the following steps need to be taken to insure a safe and efficient start up. This information is recorded on the STOCK *Installation Qualification* document.

Typical start up sequence:

1. I/O and Electrical check out.
2. Retort Survey
3. Mechanical and Dry Test of valves and controls.
4. Wet Test of valves and controls requires completion of proper utility connections:
 - a. Electrical, Steam, Water, Air and Drain.
5. Initial Testing and Control Optimization with recipe.
6. Temperature Distribution testing.
7. Heat Penetration testing.
8. Operation and Maintenance training.
9. Retort Validation.
10. Initial Product Run.
 - a. A minimum of one retort charge of baskets with ballast (preferably actual product containers filled with water) will be need after wet testing in order to properly set machine operating parameters. If diverse containers and/or product should be considered, representative containers from each product will need to be available.

Stock personnel will make every effort to verify proper operation of the equipment prior to releasing the unit to the customer. It is the customers' responsibility to determine when function and operating experience is sufficient to release the equipment for production purposes.

SECTION 2 - SYSTEM SECURITY

a. General

- **ICON^{SE}** Control Systems are designed to be compliant with CFR 21 Part 11 regulations concerning “Electronic Records: Electronic Signatures”
- **ICON^{SE}** Control Systems require a *User Name & Password* to be entered each time there is a user input that requires saving the change to a field.
- It is the responsibility of the “Individual User” to protect the security of their password and change them on a routine basis.
- It is also the responsibility of the customer to determine which level of access should be granted to personnel. Stock will configure passwords initially and train the customers Administrator on adding, deleting and changing user privileges.

b. Security Levels

- **Administrator** - has the ability to make the highest level changes to Windows, **ICON^{SE}** user password information, manage the installed PC software and hardware.
 - Unlimited access
- **Manager** - has the ability to completely operate the **ICON^{SE}** system including making modifications to and creating new *recipes*.
 - No access to SQL Server Database or changes to Windows
- **Operator** - has the ability to run the retort, place holds on, pauses on and abort the process
 - No access to Recipe Management functions, SQL Server Database and changes to Windows
- **Guest** - has ability to view current screen only
 - No access beyond Logon

c. Managing User Accounts


- System Administrator level access is required to manage user accounts.
- Accounts must be changed in both the ICON^{SE} application and the Windows operating system.

Step 1 – Shut down ICON SE and Windows system

- Select Shut Down PC button
- Power off PC
- Attach Windows Keyboard and Mouse to HOST PC
- Restart HOST PC See Section 4(d) for procedure

Step 2– Exit ICON SE system


- Login as Administrator
- On Overview Screen, Select Exit ICON SE button to gain access to Windows desk top page



- Log off current windows user
- Login windows user with administrator privileges


Step 3 – Windows User Account Administration

- Select Windows Menu: Start → Settings → Control Panel




Step 4 – Windows User Account Administration

- Select Windows Menu: Control Panel → Users and Passwords




Step 5 – Windows User Account Administration

- Select Windows Menu: Users and Passwords → Advanced Tab → Advanced button




Step 6 – Windows User Account Administration

- Select Users folder




Step 7 – Windows User Account Administration – Local Users & Groups

- Right Click on Users folder
- Select New User



Step 8 – Windows User Account Administration – User Information

- Fill in all fields as per corporate IT standards
- When finished Select Create button



The image shows a Windows-style dialog box titled "New User". It contains several input fields and checkboxes. The fields are: "User name:", "Full name:", "Description:", "Password:", and "Confirm password:". Below these fields are four checkboxes: "User must change password at next logon" (checked), "User cannot change password", "Password never expires", and "Account is disabled". At the bottom right of the dialog are two buttons: "Create" and "Close".

New User ? X

User name:

Full name:

Description:

Password:

Confirm password:

☒ User must change password at next logon

☐ User cannot change password

☐ Password never expires

☐ Account is disabled

Create Close


d. Changing Windows User Account Passwords

General

- See SECTION 2(c) to access this page


Setting Password

- Right click on the windows user account you wish to modify.
- Select Set Password



Entering Password

- Enter information into each field right click OK



Confirming Password Change


- Click OK



e. Deleting Windows User Account


General

- See SECTION 2(c) to access this page
- Select Users
- Right click on User to be removed
- Select Delete



Deletion Warning

- Click Yes to delete this user




f. Managing User Accounts in RS View

General

- See SECTION 2(c) to access this page
- You must be logged into the PC as a user with Administrator privileges.


Procedure

- Follow the path:
 - Select Windows Start → Programs → Rockwell Software → RSView Enterprise → Tools → RSView Administration Console.




Opening Application

- Open Application Explorer in RSView Administration Console
- Select New/Open Supervisory Edition Distributed Application
- Click on Existing tab
- Click on ICON SE




Selecting User Accounts

- Double click on User accounts to open RS View User Accounts




Accessing User Accounts

- Left click on the Add User / Group button




Adding User Accounts

- Select (highlight) the user to be added
- Click the ">" button to add the selected user




Deleting User Accounts

- Select RSView User Accounts to be deleted
- Click Remove button



Setting User Privileges

- Select User Account
- Check / Uncheck security codes as per note below
- Save and Close when finished



NOTES:		
Security Level	Active Codes	Setting
Operators	B & C	set to N
Managers	C	set to N
Administrators	A & B	set to N

SECTION 3 – HOST COMPUTER

a. Software and Hardware Requirements

Before You Begin

Before you begin to work with this system you should be familiar with using a Personal Computer (PC). This manual assumes that you have a working knowledge of a PC. If you are not comfortable with the PC operation please read the user manual for the PC first.

Information for Stand Alone Retort Installations

ICON^{SE} provides operator interactions to all available functions of a STOCK retort. STOCK has developed software applications that are used to generate, store, modify and download specific recipes to STOCK Retorts. Additionally, ICON^{SE} provides Sterilization Reports that are *accepted by FDA and USDA in lieu of manual records*. This report is automatically collected and printed at the end of each processing run.

NOTES:
The printer should be located in a climate-controlled environment suitable for sensitive electronic components.

Time and Date Management

See System Administrator to set time and date.

Hardware Specification

COMPUTER	Allen Bradley 6181 Industrial Computer
----------	--

Software Specification

Manufacturer	Program / ID	Version
Microsoft	MSSQL SQL Server 2000	Personal Edition
Microsoft	Office XP (Word and Excel)	Small Business Edition
Rockwell	RSView SE Client	2.10
Rockwell	RSView SE Server (25 Display)	2.10
Rockwell	RSSQL Professional1500 TAG	5.0
Rockwell	RS Linx for RSView	2.4 Included w/ Review SE

SECTION 4 - ICON^{SE} STARTUP, SHUT DOWN & LOGIN PROCEDURES

a. Utility Start - Up Procedure

- Turn on
 - Water Supply
 - Main Electrical Service (If shutoff) Follow proper safety procedures.
 - Air Supply – Regulated to 85 psi \pm
 - Steam Supply – Regulated to 85 psi minimum

b. Retort Power-Up Procedure

- Power to Retort
 - Turn on power switch on Front Panel

c. Software Start - Up Procedure


- Power to Human Machine Interface (HMI)
 - Turn on power to UPS Battery back up inside of front panel
- Wait for Operating system software to load

d. Software Reboot Procedure


- Exit windows per standard Microsoft Windows procedure: Windows Menu Start → Shut Down → Shut Down
- Power off UPS Battery back up inside of front panel: Turn on UPS Battery back up

e. Login Procedure

- Appropriate system access will be granted based upon security setting
- Login– Select button on Overview Screen to gain access to ICON^{SE} system (Fig. 5.1)
 - User and Password – Select a field on Login prompt, select OK after all entries have been made



- Enter text on Keyboard, Select Enter button



SECTION 5 - ICON^{SE} HUMAN MACHINE INTERFACE

a. General Information


- Retort **HUMAN MACHINE INTERFACE (HMI)** screens are **TOUCH SCREENS**.
 - All information is entered on the **HMI** screens.
 - Toggle buttons, touch fields, Pop-up Key Pads or Keyboards are used to access or input data.
 - **DO NOT** use a marking pen or sharp instrument to enter information on the **HMI** touch screen as it may be damaged.
-

b. Interface and Input Screen Examples

- **Overview Screen** – First HMI screen to appear, contains buttons to shut down the applications
- **Main Menu** – Will appear on most screens and is located on the left hand side of screens.
- **Key Board** – Use for Text inputs
- **Key Pad** – Use for Numerical inputs
- **Recipe Management** – Use to set recipe specific parameters.
- **Step Management** – Used to Copy Move or Delete steps
- **Recipe Settings** – Sets parameters for use in **all recipes** within a **Operation Mode**
- **Select Product Code** – Displays a list of recipe codes to chose from
- **Setpoint Input** - For modification of setpoint data.
- **Report Generation Form: Select Batch ID** – User generated reports from a list of processes.
- **Login Screen** – To Logon user to system
- **Product Registration** – Assigns the product a place in the SQL Server Database
- **Update Confirmation** – Used to verify the recipe description prior to saving changes.
- **Custom Table Settings** – For process variable information (Process Authority Input only)
Contains the range of acceptable Initial Temperatures and Retort Temperatures used to calculate process time.
- **String Input** – To enter a text description for the recipe. Part of the registration process
- **Download Confirmation** – Verification that the user wants to **Download** recipe to HOST PC for use in **NEXT COOK**
- **Retort Screen** – Real time display of Retort: piping, valves, temperatures, pressures, level sensors, rotation, set point & actual values, holds, pauses, step description, user input prompts and process times.
- **Start Confirmation** – Allows operator chance to wait before process begins and confirm information prior to process startup.
- **IT Configuration** – For setting the prompt for IT (Initial Temperature)
- **Pause Confirmation** – Confirms operator wants to “Pause” process
- **Remove Pause & Continue** - Confirms that operator wants to continue process
- **Hold Confirmation** – Confirms operator wants to “Hold” process
- **Remove Hold Confirmation** - Confirmation that operator wants to continue process
- **Abort Confirmation** - Confirms operator wants to “Abort” process
- **User Input Confirmation** – Prompts for MIG, Chart, Pressure & Water Level
- **Alarm Summary** - Operator access to view & acknowledge presence of alarms.
- **Operational Range of Set Points and Fields** – Indicates the ranges for values for specific feilds
- **Input Validation** – Allows operator to review User Input Entries before saving
- **Trending** – Shows real time data for Process Vessel & Storage Vessel: Temperature and Pressure

Overview Screen (Fig. 5.1)

- Used to access the various operating features of the *ICON^{SE}* system.



Button	Function
Exit ICON SE	Exit ICON ^{SE} shuts down HMI screen and program – Process will still run
Shutdown PC	Shut Down PC - Logs Out of system

Main Menu (Fig. 5.2)

- Used to access the various operating features of the *ICON^{SE}* system.

STOCK **Recipe Management Screen** Current User: **MANAGER1**
Thursday, April 10, 2003 11:07:18 AM

Product Code:
 Product Code:
 Container Size: 0.000000
 Container Type: 0.000000

Step Number: **01**

Step Type: Error

PROCESS VESSEL

Temperature: Setpoint 0.0 Deg.F Gradient 0.0 Deg.F
 Rotor: Speed 0.0 RPM Position Error

STORAGE VESSEL

Temperature: Setpoint 0.0 Deg.F

System Pressure: Setpoint 0.0 PSI Gradient 0.0 PSI

MISC

Time: Setpoint 0 ☐ Hold 0 : 00

Programmable Contacts:

☐ Contact #1
☐ Contact #2
☐ Contact #3
☐ Contact #4
☐ Contact #5

STEP MANAGEMENT


Source Step: 1
 Destination Step: 32

ICON^{SE}

Field or Button	Function
Overview	Access to Main Menu, Exit <i>ICON^{SE}</i> & Shut Down PC - Log Out buttons
Recipe Management	Used to set parameters used in a specific recipe
Recipe Settings	Used to set parameters used in all recipes (Global Settings)
Retort	Shows the operational screen used during the run
Trends	Graphical representation of key operational parameters on a real time basis during process
Reports	Used for accessing the various reports available
Alarms	Access to the list of current alarms
Login	Required before any changes can be made


Keyboard (Fig. 5.3)

- Used for text inputs: ex. User names and passwords



Key Pad (Fig 5.4)

- Used to make numerical inputs onto the *ICON^{SE}* user *HMI* interface screens.
- Depending on what information is required the key pad appearance may change slightly.



Button	Function
ESC	Returns to previous screen
Back	Deletes last entry
Clear	Deletes entire entry
Accept	Enters data into program

Recipe Management Screen (Fig 5.5)

- Set information for any given recipe step to suit processing needs.
- Access by selecting the *Recipe Management* button on left hand *Main Menu*.
- Change information by use of *toggle buttons* or *touch fields*.

The screenshot shows the 'Recipe Management Screen' interface. At the top, it displays 'Current User: MANAGER1' and the date/time 'Thursday, April 10, 2003 11:32:56 AM'. The main area contains fields for 'Product Code: 32767', 'Revision: 7', 'Product Desc.: Test Recipe Created 02-13-03 by TS', 'Container Size: Ballast', and 'Container Type: Ballast'. Below these are 'SELECT' and 'DOWNLOAD' buttons. A 'Step Number' field is set to '01'. A row of buttons labeled 'STEP 1' through 'STEP 7' is shown, with 'STEP 1' highlighted. A 'Step Type' dropdown is set to 'Heating SV'. The 'PROCESS VESSEL' section includes 'Temperature' (Setpoint, Gradient) and 'System Pressure' (Setpoint, Gradient) fields. The 'STORAGE VESSEL' section includes 'Temperature' (Setpoint) and 'Rotor' (Speed, Position) fields. A 'Misc' section has 'Time' (Setpoint, Hold) fields. A 'Programmable Contacts' section lists 'Contact #1' through 'Contact #5'. A 'STEP MANAGEMENT' section has 'Source Step' (1), 'Destination Step' (32), and 'MOVE', 'COPY', 'DELETE' buttons. Callouts point to various elements: 'Select Recipe Management Screen - select the menu button' points to the 'RECIPE MANAGEMENT' button in the left sidebar; 'Touch Fields' points to the 'Product Code' and 'Revision' fields; 'Touch Buttons' points to the 'STEP 1' button; 'Toggle Button' points to the 'Heating SV' dropdown; 'Touch Fields' points to the 'Temperature Setpoint' and 'System Pressure Setpoint' fields; 'Touch Fields' points to the 'Time Setpoint' field; 'Touch Fields' points to the 'Contact #1' through 'Contact #5' checkboxes; 'Touch Fields' points to the 'Source Step' and 'Destination Step' fields; and 'Touch Buttons' points to the 'MOVE', 'COPY', and 'DELETE' buttons.

Field or Button	Function
Select Button	Selects a list of recipes to choose from
Recipe Settings	Used to set parameters used in all recipes (Global Settings)
Registration	Assigns the new recipe a position in the SQL Server Database
Step Type	Indicates what processing step is located on a particular step number: S1, S2, S3, C1 ...etc
Temperature / Pressure Set Points	Temperature or pressure set point for the step
Gradient	Positive rate of temperature or pressure change per minute during the set point time
Misc. Time Set point	Total time of the step entered in seconds (Minutes and Seconds will automatically calculate)
Rotor Speed	RPM from 7 to 30
Rotor Position	A = Horizontal, B = Custom, C = Custom
Hold	Places a hold on the process at the end of the step. A user entry is required to continue.
Step Management	Used to Move, Copy or Delete a step
Source Step	Is the step that is chosen for Moving, Copying or Deletion
Destination Step	Is the step that is chosen for information to be Moved to, Copied to
Programmable Contacts	Used for adding devices to the operational control panel.

Step Management (Fig. 5.6)

- Access function - select Recipe Management button on left hand Main Menu
- Copy, Move or Delete – Select button to perform function for any given recipe step.
- Source Step - step to Copy, Move or Delete.
- Destination Step - location desired for the Copied or Moved step to be pasted to.
- Delete - removes the step.
 - Change information by use of Key Pad pop up screen

The screenshot displays the 'Recipe Management Screen' for 'Current User: MANAGER1' on 'Thursday, April 10, 2003 1:13:54 PM'. The interface includes a left-hand menu with buttons for OVERVIEW, RECIPE MANAGEMENT (highlighted), RECIPE SETTINGS, PROCESS TABLE, RETORT, TRENDS, REPORTS, ALARMS, and LOGIN. The main area shows product details (Product Code: 3, Revision: 1, Product Desc.: Example for Product Registration Confirmation, Container Size: Ballast, Container Type: Ballast) and a grid of steps (STEP 1 to STEP 7, with STEP 1 highlighted). Below the steps, there are fields for Step Type (Heating SV), PROCESS VESSEL (Temperature, Gradient, System Pressure), Rotor (Speed, Position), and STORAGE VESSEL (Temperature). A 'Touch fields' callout points to the 'Touch fields' button. The bottom right section contains 'STEP MANAGEMENT' buttons (MOVE, COPY, DELETE) and 'Source Step' (01) and 'Destination Step' (32) fields. A 'Touch Button to call up key pad??' callout points to the 'MOVE' button. The bottom left corner features the 'ICON^{SE}' logo.

Field or Button	Function
Move Button	Moves data from <u>Source Step</u> to <u>Destination Step</u>
Copy Button	Copies data from <u>Source Step</u> to <u>Destination Step</u>
Delete Button	Deletes step that is indicated in <u>Source Step</u> box
Source Step	Is the step that is chosen for <u>Moving</u> , <u>Copying</u> or <u>Deleting</u>
Destination Step	Is the step that is chosen for information to be Moved to or Copied to

Recipe Settings (Fig. 5.7)

- Access by selecting the Recipe Settings button on left hand main menu
- All recipes created in a specific Operation Mode use this information. (Ex: FWI is Full Water Immersion)
- Change information on screen by use of toggle buttons or key pads / touch fields
- Alarm Tolerances are to be set in conjunction with a **Process Authority** and can be used as the basis for deviation analysis

The screenshot shows the 'Recipe Settings' interface. At the top, it displays 'Current User: MANAGER1' and the date/time 'Thursday, April 10, 2003 11:35:32 AM'. The left sidebar contains buttons for 'STOCK', 'RECIPE SETTINGS' (highlighted), 'PROCESS TABLE', 'RETORT', 'TRENDS', 'REPORTS', 'ALARMS', and 'LOGIN'. The main area is divided into sections: 'Operation Modes' with a 'Sterilization' toggle set to 'FWI'; 'Alternate Process' with a 'Table Method' toggle set to 'CUSTOM'; 'ALARM TOLERANCES' with a table of parameters; 'General Information' with checkboxes for 'Prompt for I.T.' and 'E.S. Mode'; and 'User Inputs' with 'Number of Inputs' and 'Input Interval #1' toggles. Callouts identify 'Touch Button to access page', 'Toggle button', and 'Touch Fields'.

ALARM TOLERANCES	
LOW	HIGH
3.0	4.0
10.0	10.0
4.0	5.0
4.0	5.0
2	2
55.0	96.0
50.0	99.0

Field or Button	Function
Sterilization (Operation Mode)	Sets type of process, FWI, Steam, Spray (Not all processes will be active, this is customer dependant)
Table Method	Custom (generated by the Process Authority)
Table	To select a table
Alarm Tolerances	Sets high and low values for selected parameters
Number of Inputs	Defines number of times a prompt for information appears
Input Interval	Defines interval at which a prompt for information appears
Prompt for IT	Places a hold on process until operator enters a value
ES Mode	Activates the <i>Energy Saving Mode</i> of operation (Optional)
Input Interval	Defines interval at which a prompt for information appears

Select Product Code (Fig. 558)

- Access screen by Selecting Select button in upper right hand corner of Recipe Management Screen
- Select Product number on screen to access information
- In Add mode enter new numbers required by use of key pad.
- Key Pad is activated by Selecting the Add button at the bottom of the screen

Select Product Code :

Product:	Revision:
1234	29
995	8
32767	7
44	4
16	3
3808	1
5678	1
666	1
2	1
1	1

Buttons: Load, Add, Print, Cancel

Button	Function
Load	Puts recipe into controller for use or modification
Add	To create new recipe in database for future use or modification
Print	To print recipe user selects from list
Cancel	Exits Screen

Set point Input (Fig. 5.9)

- Access by selecting a touch field on Recipe Management Screen
- Set point information is changed by use of the key pad

Setpoint Input

Step 01: SV Temperature SP Value

Max: 302.0 Min: 32.0

Buttons: ACCEPT, CANCEL

Touch field to call up key pad

STOCK

Button	Function
Accept	Enters the data into the recipe
Cancel	Exits Screen

Report Generation Form – Please Select Batch ID (Fig. 5.10)

- Report generation for cooks that are on the Batch ID list.
- Cooks are generated by selecting the desired Batch ID then selecting the reporting option

Report Generation Form - Please Select Batch ID

Batch ID: 8831028332142003 Retort Number: 883 Product Code: 32767 Recipe Revision: 2 Start Time: 2/14/2003 10:28:33 AM

Touch number Field

Sterilization Report Recipe Report Cancel

Button	Function
Batch ID	Touch field that is used to select the Batch ID# to be reported
Sterilization Report	Allows sterilization record to be printed for a chosen Batch ID
Recipe Report	Allows recipe record to be printed for a chosen Batch ID

Login (Fig. 5.11)

- Required before permanent changes to data will be granted
- Select a touch field on the screen and enter information on Key Board. (Fig 5.3)

Login

Type your user name and password:

User name: manager Password: xxxxxx

Touch Field

OK Cancel

Touch Field

Product Registration (Fig. 5.12)

- Used to confirm recipe and add information specific to the Product Code in text boxes
- Select a touch field on the screen and enter information on Key Board. (Fig 5.3)

Field or Button	Function
Confirm	Allows data to be entered into the recipe
Cancel	Exits Screen
Text Fields	Dialog box filled in by keyboard

Update confirmation (Fig. 5.13)

- Used to confirm Product Code and Revision selected for updating is correct

Button	Function
Confirm	Allows data to be entered into the recipe
Cancel	Exits Screen

Custom Table Settings (Fig. 5.14)

- Used to set process variables for retort temperature and Initial temperature
- Manual entry fields data is accessed by touch field and key pad

STOCK

OVERVIEW

RECIPE MANAGEMENT

RECIPE SETTINGS

PROCESS TABLE

RETORT

TRENDS

REPORTS

ALARMS

LOGIN

ICON^{SE}

Custom Table Settings

Current User: MANAGER1
Thursday, April 10, 2003 11:56:12 AM

Custom Process Table

	Process Vessel Temperature									
I.T.	246.0	248.0	250.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
45.0	420	390	360	0	0	0	0	0	0	0
50.0	380	365	340	0	0	0	0	0	0	0
55.0	330	325	320	0	0	0	0	0	0	0
0.0	0	0	0	0	0	0	0	0	0	0
0.0	0	0	0	0	0	0	0	0	0	0

Note: Times are entered in Seconds.

Touch the fields to call up Keypad

NOTE:

This is CRITICAL part of the thermal process do not change these values without consulting a Thermal Process Authority

String Input (Fig. 5.15)

- Text box for Product Description
- Found through Recipe Button on main menu

Field or Button	Function
Accept	Enters text into the Global Recipe Setting page
cancel	Quits function and exits screen
Comments	Dialog box filled in by keyboard


Download Confirmation (Fig. 5.16)

- Confirmation of the recipe to be downloaded and comments if desired.

Field or Button	Function
Confirm	Confirm the recipe is the correct one to change
Cancel	Exits Screen
Comments	Dialog box filled in by keyboard

Retort Screen (Fig. 5.17)

- This is the operational screen for the *ICON^{SE}* controller.
- The screen may change appearance as processing steps are completed
- Analog valves and level indicators indicate the % open on the display
- Digital Valves and motors are on or off
- The entire process is monitored from this screen
 - Valves, pumps, temperatures & pressures (set points & actual), water level, step time, Rotor Position, Water Supply, Brake, Steam Supply, No Flow Warning, Door Closed and RPM



Button	Function
Start	Begin process

Start Confirmation (Fig. 5.18)

- Prompt for confirmation that the displayed cook information is correct and entry of cook number

The 'Start Confirmation' screen displays the following information:

- Start of Cook:**
- PRODUCT CODE:** 32767
- REVISION:** 2
- DATE & TIME:** Friday, February 14, 2003 10:24:14 AM
- COOK NUMBER:** 2141 (with a blue touch field next to it)
- YES** and **NO** buttons
- STOCK** button

A callout box labeled 'Touch Field' points to the blue area next to the cook number.

Field or Button	Function
Cook Number	To assign a reference number to a specific cook

IT Configuration (Fig. 5.19)

- Setting the prompt for IT (Initial Temperature) found in Recipe Settings
- If selected IT must be entered before the process can begin


The 'IT Confirmation' screen displays the following information:

- Please Enter Initial Temperature:**
- PRODUCT CODE:** 32767
- REVISION:** 2
- DATE & TIME:** Friday, February 14, 2003 10:41:49 AM
- INITIAL TEMP.:** 45.0 (with a blue touch field next to it)
- YES** and **NO** buttons
- STOCK** button

Field or Button	Function
Initial Temp	Value the <u>Process Tables</u> references to set process time

Pause Confirmation (Fig. 5.20)

- Prompts for confirmation that the operator wants to pause the process
- Pause stops the process and returns all pumps and valves to safe (closed) condition
- Pause can be activated at any time during the process




The dialog box is titled "Pause Confirmation" and "Pause Current Process?". It contains fields for "CURRENT STEP:" (value 1), "DATE & TIME:" (Friday, February 14, 2003 10:36:10 AM), and "REASON:" (Maint. repair on SV Heating valve). There are "YES" and "NO" buttons at the bottom right, and a "STOCK" button at the bottom left.

Field or Button	Function
Reason	To assign text to explain cause of event

Remove Pause & Continue Process (Fig. 5.21)

- Resumes the process from the point that the Pause was entered.
- Restarts pumps, resets valves to run positions and finishes any remaining time.
- Prompts for confirmation that the operator wants to continue the process
 - Text can be added in the "Reason" dialog box via Keyboard screen (fig 5.3)




The dialog box is titled "Remove Pause & Continue Confirmation" and "Remove Pause & Continue Process?". It contains fields for "CURRENT STEP:" (value 7), "DATE & TIME:" (Friday, February 14, 2003 11:19:55 AM), and "REASON:" (Maint. fixed Door). There are "YES" and "NO" buttons at the bottom right, and a "STOCK" button at the bottom left.

Field	Function
Reason	To assign text to explain event

Hold Confirmation (Fig. 5.22)

- Prompt for confirmation that the operator wants to place a hold in the process
- Hold keeps the process in the current step indefinitely & can be placed at any point in the process
- Text can be added in the "Reason" dialog box




The dialog box is titled "Hold Confirmation" and "Hold this Cook?". It contains fields for "PRODUCT CODE" (32767), "REVISION" (2), and "DATE & TIME" (Friday, February 14, 2003 10:39:10 AM). A "REASON:" field contains the text "Maint. to work on door switch". There are "YES" and "NO" buttons at the bottom right, and a "STOCK" button at the bottom left.

Field or Button	Function
Reason	To assign text to explain

Remove Hold Confirmation (Fig. 5.23)

- Prompts for confirmation that the operator wants to remove the Hold and finish remaining time in the process step.
- Text can be added in the "Reason" dialog box via Keyboard screen
- To remove hold select Yes



The dialog box is titled "Remove Hold Confirmation" and "Remove Cook Hold?". It contains fields for "CURRENT STEP" (3), "DATE & TIME" (Friday, February 14, 2003 10:53:21 AM), and "REASON:" (Maint done with repair). There are "YES" and "NO" buttons at the bottom right, and a "STOCK" button at the bottom left.

Field or Button	Function
Reason	To assign text to explain

Abort Confirmation (Fig. 5.24)

- This stops the process and returns the valves to a safe condition.
- Prompts for confirmation that the operator wants to Abort the process
- Text can be added in the "Reason" dialog box via Keyboard screen
- Select Yes button to Abort cook

Field	Function
Reason	To assign text to explain

User Input Confirmation (Fig. 5.25)

- Input will be used to reference process tables to recalculate process time if MIG reading is below process temperature.
- Signaled by alarms and prompts for operator input and confirmation of MIG, Chart Temp, System Pressure, RPM, PV Level.
- Process will remain in SIII until inputs are entered,
- User and password will be verified before data entry

Field or Button	Function
MIG Temp field	Enter in reading for MIG
Chart Temp field	Enter in reading Chart
System Pressure field	Enter in reading System Pressure
Rotor RPM field	Enter in reading for rotation RPM
PV Level field	Water level in process vessel
Confirm button	Acknowledges the readings are correct

Note:

MIG reading entered must be higher than chart reading. An Input Validation screen appears for confirmation of the entered readings. See manager if condition exists

Alarm Summary (Fig. 5.26)

- Lists alarms that occurred during a cook.
- Automatically prints at the end of cook cycle
- Alarm Indications
 - Blinking Light or Horn - Indicates that an alarm condition exists for prompt for user inputs.
 - Steady Light or Horn – Critical Alarm and needs to be evaluated immediately

STOCK **Alarm Summary** Current User: MANAGER1
Thursday, April 10, 2003 8:32:47 PM

Alarm Time	Alarm Date	Tag Description	Tag Value
8:32:18 PM	4/10/2003	Retort 883: High System Pressure Alarm	0
8:32:08 PM	4/10/2003	Retort 883: High System Pressure Alarm	1

Touch Button Touch Button Touch Button

ICON^{SE} Ack Current Ack Page Ack All

Button	Function
Ack Current	Operator acknowledges the selected alarm
Ack Page	Operator acknowledges all alarms on the current page
Ack All	Operator acknowledges all of the alarms that have occurred during the entire process

Operational Range of Set Points and Fields (Fig 5.27)

- Set points and recipe parameters are specific to the customer.
- The following screen shows the range of possible set points


The screenshot displays the 'Recipe Management Screen' with the following details:

- Header:** STOCK icon, 'Recipe Management Screen' title, 'Current User: MANAGER1', and timestamp 'Thursday, April 10, 2003 11:32:56 AM'.
- Navigation Sidebar:** OVERVIEW, RECIPE MANAGEMENT (selected), RECIPE SETTINGS, PROCESS TABLE, RETORT, TRENDS, REPORTS, ALARMS, LOGIN, and ICON^{SE}.
- Main Content Area:**
 - Product Info:** Product Code: 32767, Revision: 7. Callouts indicate ranges: '0 - 32767' for Product Code and '0 - 100' for Revision.
 - Container Info:** Container Size: Ball, Container Type: Ballast.
 - Step Selection:** Step Number: 01. Callout indicates range '01 - 32'.
 - Step Progress:** A row of buttons for STEP 1 through STEP 16, with STEP 1 highlighted in green.
 - Step Configuration:**
 - Step Type:** Heating SV.
 - PROCESS VESSEL:**
 - Temperature:** Setpoint (0 - 302 °F), Gradient.
 - System Pressure:** Setpoint (30.0 PSI, range 0 - 60 PSI), Gradient (0.0 PSI).
 - MISC:** Time: Setpoint (0 - 32767 seconds), Hold checkbox.
 - Rotor:** Speed (0.0 RPM, range 0, 7 - 25 RPM), Position (Horiz).
 - STORAGE VESSEL:** Temperature: Setpoint (260.0 Deg.F, range 0 - 302 °F).
 - STEP MANAGEMENT:** Source Step: 1, Destination Step: 32. Callouts indicate ranges '00 - 32' for both.
 - Buttons:** MOVE, COPY, DELETE.

Parameter	Description
Process Vessel Temperature Set Point	Temperature the system will achieve during step time
Process Vessel Temperature Gradient	Positive rate of temperature change per minute during the set point time
System Pressure Set Point	Pressure the system will try to achieve and maintain during step time
System Pressure Gradient	Positive rate of Pressure change per minute during the set point time
Step Type	Describes the process step verbally
MISC Time Setpoint	Defines the Step Time
Hold	Used to set a hold at the END of the process step
Programmable Contacts	Used for setting up optional devices, stays active for entire step if activated
Rotor Speed	Speed that will be maintained during step time
Rotor Position	Position of the rotor (A = Horizontal, B and C = custom positions)


Input Validation (Fig 5.28)

- User input validation screen allow the operator the chance to recheck readings for MIG, Chart Temp, System Pressure, Rotor RPM and Process Vessel water level. Process deviations may result form faulty readings.



Trending Screen (Fig 5.29)

- Trending screen show real time data for the Process & Storage Vessel Temperature & Pressure.
- Allow operator to see a graphical representation of the performance of the selected parameters



SECTION 6 - RECIPE MANAGEMENT

a. Loading Existing Recipes

Step 1 - Select Product Code

- Select the "Select" button on the Recipe Management Screen (Fig 5.5)

The screenshot shows the 'Recipe Management Screen' with a sidebar on the left containing buttons: STOCK, OVERVIEW, RECIPE MANAGEMENT (highlighted), RECIPE SETTINGS, PROCESS TABLE, RETORT, TRENDS, REPORTS, ALARMS, and LOGIN. The main area has a top header with 'Current User: MANAGER1' and 'Thursday, April 10, 2003 12:10:16 PM'. Below this are input fields for Product Code (0), Revision (0), Product Desc. (0.000000), Container Size (0.000000), and Container Type (0.000000). A 'SELECT' button is next to the Revision field, with a callout pointing to it saying 'Select the "Select" button'. Below these are Step Number (01) and a grid of red buttons. Further down are sections for PROCESS VESSEL (Temperature, Gradient, System Pressure), STORAGE VESSEL (Temperature), and MISC (Time, Hold, Programmable Contacts). The STEP MANAGEMENT section at the bottom right includes Source Step (1), Destination Step (32), and buttons for MOVE, COPY, and DELETE.

Fig 6.1

Step 2 - Load Product Code

- Select Product Code screen will appear. (Fig 5.7)
 - Select field to select recipe to load before selecting Load button
 - Select Load button – wait until Product Code loads before proceeding

The screenshot shows the 'Select Product Code' dialog box with two columns: Product and Revision. The Product column lists codes: 1234, 995, 32767, 44, 16, 3808, 5678, 666, 2, and 1. The Revision column lists numbers: 29, 8, 7, 4, 3, 1, 1, 1, 1, and 1. A callout box labeled 'FIRST' points to the 'Product' column with the text: 'Select Product Code to be loaded Example Prod Code 32767 Rev 7 will be loaded'. Another callout box labeled 'SECOND' points to the 'Load' button with the text: 'Select Load Button'. The dialog box has buttons for Load, Add, Print, and Cancel.

Fig 6.2

Step 3 - Loading Completed

- The Recipe is now Product Code "32767", Revision "7".

STOCK **Recipe Management Screen** Current User: **MANAGER1**
Thursday, April 10, 2003 11:32:56 AM

Product Code: Revision: **SELECT**

Product Desc.: **DOWNLOAD**

Container Size: **Product Code**

Container: **Revision Number is still "7" because no changes were made to existing product code**

Step Number:

STEP 1 **STEP 2** **STEP 3** **STEP 4** **STEP 5** **STEP 6** **STEP 7** **STEP 8** **STEP 9** **STEP 10** **STEP 11** **STEP 12** **STEP 13** **STEP 14** **STEP 15** **STEP 16** **STEP 17** **STEP 18** **STEP 19** **STEP 20**

Step Type

PROCESS VESSEL **STORAGE VESSEL**

Temperature: Setpoint Deg.F **Rotor:** Speed RPM **Temperature:** Setpoint Deg.F

Gradient Deg.F **Position**

System Pressure: Setpoint PSI **Gradient** PSI

MISC **Programmable Contacts:** **STEP MANAGEMENT**

Time: Setpoint ☐ Hold : ☐ Contact #1 ☐ Contact #2 ☐ Contact #3 ☐ Contact #4 ☐ Contact #5

Source Step: **Destination Step:** **MOVE** **COPY** **DELETE**

ICON^{SE}

Fig 6.3

b. Clearing Displayed Recipe

General

- Recipes can be cleared from the Recipe Management Screen after being loaded (Fig 5.5)
- Select the Select button

The screenshot shows the 'Recipe Management Screen' with a sidebar on the left containing buttons: STOCK, OVERVIEW, RECIPE MANAGEMENT, RECIPE SETTINGS, PROCESS TABLE, RETORT, TRENDS, REPORTS, ALARMS, LOGIN, and ICON^{SE}. The main area displays recipe details for 'Product Code: * 3' and 'Revision: 0'. A callout box points to the 'SELECT' button, stating: 'Select the Select button to call up Select Product Code screen'. Below this, there are fields for 'Product Desc.: 0.000000', 'Container Size: 0.000000', and 'Container Type: 0.000000'. A 'Step Number' field shows '01'. A row of red buttons represents steps, with 'STEP 1' highlighted. Below this is a 'Step Type' dropdown set to 'Heating SV'. The 'PROCESS VESSEL' section includes 'Temperature' (Setpoint, Gradient) and 'Rotor' (Speed, Position) fields. The 'STORAGE VESSEL' section includes 'Temperature' (Setpoint) and 'System Pressure' (Setpoint, Gradient) fields. The 'MISC' section includes 'Time' (Setpoint, Hold) and 'Programmable Contacts' (Contact #1 to #5). The 'STEP MANAGEMENT' section includes 'Source Step' (1), 'Destination Step' (32), and buttons for 'MOVE', 'COPY', and 'DELETE'.

Fig 6.4

- Select the Cancel button on the Select Product Code screen. (Fig 5.8)

The screenshot shows the 'Select Product Code' dialog box. It has two columns: 'Product' and 'Revision'. The 'Product' column lists 1234, 995, 3808, and 5678. The 'Revision' column lists 29, 2, 1, and 1. At the bottom are buttons for 'Load', 'Add', 'Print', and 'Cancel'. A callout box points to the 'Cancel' button, stating: 'Select Cancel button to remove Product Code from screen'.

Fig 6.5

c. Creating a New Recipe & Recipe Parameters

General

- Creating a blank template

Step 1 – Add a New Recipe

- Select the Select button on the Recipe Management screen (Fig 5.5)

The screenshot shows the 'Recipe Management Screen' with a sidebar on the left containing buttons: STOCK, OVERVIEW, RECIPE MANAGEMENT, RECIPE SETTINGS, PROCESS TABLE, RETORT, TRENDS, REPORTS, ALARMS, LOGIN, and ICON^{SE}. The main area displays fields for Product Code (0), Revision (0), Product Desc. (0.000000), Container Size (0.000000), and Container Type (0.000000). A 'SELECT' button is in the top right. A callout bubble points to it with the text: 'Select Select button to call up Select Product Code screen'. Below these fields is a 'Step Number' field set to '01' and a row of red buttons. Further down are sections for 'PROCESS VESSEL' (Temperature, Gradient, System Pressure), 'STORAGE VESSEL' (Temperature), 'MISC' (Time, Hold), and 'STEP MANAGEMENT' (Source Step, Destination Step, MOVE, COPY, DELETE buttons). A 'Position' field shows 'Error'.

Fig 6.6

- Select Add button on the Select Product Code screen. (Fig.5.8)

The screenshot shows a 'Select Product Code' dialog box with two columns: 'Product' and 'Revision'. The 'Product' column lists 1234, 995, 3808, and 5678. The 'Revision' column lists 29, 2, 1, and 1. At the bottom are 'Add', 'Print', and 'Cancel' buttons. A callout bubble points to the 'Add' button with the text: 'Select Button'.

Fig 6.7

Step 2 - Choosing a Step

1. Select a recipe Step Number field to configure
2. Select Step Type using arrows to toggle through available step descriptions
3. Asterisk ("*") appears in Product Code field indicating changes have been made that need saving

STOCK **Recipe Management Screen** Current User: MANAGER1
Thursday, April 10, 2003 12:27:58 PM

Product Code: * 3 Revision: 0 SELECT

Product Desc.: 0.000000 REGISTER

Container Size: 0.000000

Container Type: 0.000000

Step Number: 01

STEP 1 Select a step number field to modify / view a STEP TYPE Select a RED field to create a new step

Step Type: Heating SV 2

PROCESS VESSEL **STORAGE VESSEL**

Temperature: Setpoint Deg.F Rotor: Speed 0.0 RPM Temperature: Setpoint 0.0 Deg.F

Gradient Deg.F Position Error

System Pressure: Setpoint 0.0 PSI Gradient 0.0 PSI

MISC **STEP MANAGEMENT**

Time: Setpoint Hold : Programmable Contacts: ☐ Contact #1 ☐ Contact #2 ☐ Contact #3 ☐ Contact #4 ☐ Contact #5

Source Step: 1 MOVE

Destination Step: 32 COPY

DELETE

ICON^{SE}

Fig 6.8

NOTE

A new "Revision Number" will be automatically added to the "Product Number" and displayed on the "Recipe Management Screen" after the recipe is **REGISTERED** or **UPDATED**.

Step 3 - Creating New or Changing Set Point Parameters - Begin

- Select recipe parameter to be modified by selecting the field. Example: Storage Vessel Temp.

STOCK Recipe Management Screen Current User: MANAGER1
Thursday, April 10, 2003 12:27:58 PM

Product Code: * 3 Revision: 0 SELECT

Product Desc.: 0.000000 REGISTER

Container Size: 0.000000

Container Type: 0.000000

Step Number: 01

STEP 1 [Red Field]

Step Type: Heating SV

PROCESS VESSEL

Temperature: Setpoint [Field] Deg.F Gradient [Field] Deg.F

Rotor: Speed 0.0 RPM Position [Error]

System Pressure: Setpoint 0.0 PSI Gradient 0.0 PSI

STORAGE VESSEL

Temperature: Setpoint 0.0 Deg.F

MISC

Time: Setpoint [Field] Hold [Field] : [Field]

Programmable Contacts:

- ☐ Contact #1
- ☐ Contact #2
- ☐ Contact #3
- ☐ Contact #4
- ☐ Contact #5

STEP MANAGEMENT

Source Step: 1 MOVE

Destination Step: 32 COPY

DELETE

ICON^{SE}

Touch Storage Vessel Set Point Field

Fig 6.10

Step 4 - Set Point - Input

- "Set point Input" screen will appear. (Fig 5.9)
 - Select the blue field and a numeric Keypad screen will be displayed for data entry.

Setpoint Input

Step 01: SV Temperature SP Value

Max: 302.0 Min: 32.0

ACCEPT CANCEL [Blue Field]

STOCK

Touch field to call up keypad

Fig 6.11

Step 5 - Set Point – Data Entry

- Enter data on Keypad screen. (Fig. 5.4)
 - To **Update Field** select the button after entries have been made to update recipe changes to the controller display




Fig 6.12

Step 6 - Set Points – Accept or Reject

- Accept or reject entered data by selecting Accept or Cancel buttons




Fig 6.13

Step 7 - Set Points – Screen Shot Finished Recipe

- Value of 260 °F for the Storage Vessel Temperature Set point is now entered for Recipe Step Number 1.


STOCK		Recipe Management Screen		Current User: MANAGER1	
				Thursday, April 10, 2003 12:33:17 PM	
 OVERVIEW RECIPE MANAGEMENT RECIPE SETTINGS PROCESS TABLE RETORT TRENDS REPORTS ALARMS LOGIN	Product Code: <input type="text" value="3"/> Revision: <input type="text" value="0"/>		<input type="button" value="SELECT"/>		
	Product Desc.: <input type="text" value="0.000"/>		<input type="button" value="REGISTER"/>		
	Container Size: <input type="text"/>				
	Container Type: <input type="text"/>				
	<div> <div>New recipe number now displayed</div> </div>				
Step Number: <input type="text" value="01"/>					
<div> <div>STEP 1</div> <div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div> </div>					
<div> <div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div> </div>					
Step Type <input type="text" value="Heating SV"/>					
PROCESS VESSEL			STORAGE VESSEL		
Temperature:		Rotor:		Temperature:	
Setpoint	<input type="text"/>	Deg.F	Speed	<input type="text" value="0.0"/>	RPM
Gradient	<input type="text"/>	Deg.F	Position	<input type="text" value="Error"/>	
System Pressure:					
Setpoint	<input type="text" value="0.0"/>	PSI			
Gradient	<input type="text" value="0.0"/>	PSI			
MISC			STEP MANAGEMENT		
Time:			Programmable Contacts:		Source Step:
Setpoint	<input type="text"/>		<input type="checkbox"/>	Contact #1	<input type="text" value="1"/>
<input type="checkbox"/> Hold	<input type="text"/>	:	<input type="checkbox"/>	Contact #2	<input type="text" value="32"/>
			<input type="checkbox"/>	Contact #3	
			<input type="checkbox"/>	Contact #4	
			<input type="checkbox"/>	Contact #5	
					Destination Step:
					<input type="button" value="MOVE"/>
					<input type="button" value="COPY"/>
					<input type="button" value="DELETE"/>

Fig 6.14

Step 8 - Step Management

- Used to copy, move or delete. Use to copy or move information from one step to another.
- Copy or Move –
 - Select Source Step field, enter step number on String Input (Fig 5.15)
 - Select Destination Step field desired for the Copied or Moved step to be pasted to.
 - Select Destination Step field, enter step number on String Input
 - Select desired function button.
- Delete –
 - Select Source Step field, enter step number on String Input
 - Select Delete function button.

The screenshot displays the 'Recipe Management Screen' for 'STOCK'. The current user is 'MANAGER1' and the date/time is 'Thursday, April 10, 2003 1:13:54 PM'. The screen is divided into several sections:

- Left Sidebar:** Contains buttons for OVERVIEW, RECIPE MANAGEMENT (highlighted), RECIPE SETTINGS, PROCESS TABLE, RETORT, TRENDS, REPORTS, ALARMS, and LOGIN. The 'ICON^{SE}' logo is at the bottom.
- Product Information:** Fields for Product Code (3), Revision (1), Product Desc. (Example for Product Registration Confirmation), Container Size (Ballast), and Container Type (Ballast). Buttons for SELECT and UPDATE are on the right.
- Step Management Section:**
 - Step Number:** 01
 - Step Type:** Heating SV
 - Process Vessel:** Fields for Temperature (Setpoint, Gradient), Rotor (Speed, Position), and System Pressure (Setpoint, Gradient).
 - Storage Vessel:** Field for Temperature (Setpoint).
 - Misc:** Fields for Time (Setpoint, Hold) and Programmable Contactors (Contact #2, Contact #5).
 - STEP MANAGEMENT:** Fields for Source Step (01) and Destination Step (32), with buttons for MOVE, COPY, and DELETE.

Callouts indicate 'Touch Field to access' for the Source and Destination Step fields, and 'Touch Button after data is entered to perform function' for the MOVE, COPY, and DELETE buttons.

Fig 6.9

Field or Button	Function
Move Button	Moves data from <u>Source Step</u> to <u>Destination Step</u>
Copy Button	Copies data from <u>Source Step</u> to <u>Destination Step</u>
Delete Button	Deletes step that is indicated in <u>Source Step</u> box
Source Step	Is the step that is chosen for <u>Moving, Copying or Deleting</u>
Destination Step	Is the step that is chosen for information to be Moved to or Copied to

Step 9 – Product Registration - SEE SECTION 6(f)

- Repeat data edits for all Steps
- Once the Product Code / Recipe has been completely updated with new information register the recipe.

d. Creating Recipes from a Template

General

- New recipes can be **added** using a template from an existing product code (recipe) that has similar operational characteristics

Step 1 – Load Product Code Template – See Section 6(a)

Step 2 - New Product Code Designation

- Select the Select button on Recipe Management Screen (Fig 5.5)

The screenshot displays the 'Recipe Management Screen' with a sidebar on the left containing buttons for 'STOCK', 'RECIPE MANAGEMENT', 'RECIPE SETTINGS', 'PROCESS TABLE', 'RETORT', 'TRENDS', 'REPORTS', 'ALARMS', and 'LOGIN'. The main area shows the 'Current User: MANAGER1' and the date 'Thursday, April 10, 2003 12:39:48 PM'. Below this, there are fields for 'Product Code: 32767' and 'Revision: 10'. A 'SELECT' button is highlighted with a callout: 'Select to call up Select Product Code screen'. Below the product code fields, there are two 'Ballast' fields and a 'DOWNLOAD' button. A 'Step Number: 01' field is shown, followed by a row of buttons labeled 'STEP 1' through 'STEP 7'. The 'STEP 1' button is highlighted with a callout: 'Product Code Loaded for use as a Template'. Below the step buttons, there are sections for 'PROCESS VESSEL' and 'STORAGE VESSEL'. The 'PROCESS VESSEL' section includes fields for 'Temperature: Setpoint', 'Gradient', 'Rotor: Speed', 'Position', 'System Pressure: Setpoint', and 'Gradient'. The 'STORAGE VESSEL' section includes a 'Temperature: Setpoint' field. Below these sections, there are 'MISC' and 'STEP MANAGEMENT' sections. The 'MISC' section includes a 'Time: Setpoint' field and a 'Hold' checkbox. The 'STEP MANAGEMENT' section includes 'Source Step: 1' and 'Destination Step: 32' fields, and buttons for 'MOVE', 'COPY', and 'DELETE'. The 'ICON^{SE}' logo is visible in the bottom left corner.

Fig 6.15

- Select Product Code screen will appear → Select Add button(Fig 5.8)
- Keypad screen will appear. (Fig 6.12)
 - Enter **NEW** Product Code Number: Select Accept button enters data into Product Code
- Make necessary changes to step parameters, recipe settings, and process tables in the same manner.

Step 3 – Update & Register Product – See Section 6 (e) (f)

e. Updating Recipes

General

- Updating a Product Code after making changes is **CRITICAL** and **MUST BE DONE** after changes have been made to a recipe.
- Failure to Update will result in the changes not being saved to the New Product Code

Step 1 - Updating of Recipe


- Update – Select the button on the Recipe Management screen
 - Keyboard - screen will appear - Enter Password and User information (Fig 5.3)

The screenshot displays the 'Recipe Management Screen' with a sidebar on the left containing buttons: STOCK, OVERVIEW, RECIPE MANAGEMENT (highlighted), RECIPE SETTINGS, PROCESS TABLE, RETORT, TRENDS, REPORTS, ALARMS, and LOGIN. The main area includes a header with 'Current User: MANAGER1' and 'Thursday, April 10, 2003 1:25:03 PM'. Below this, fields for 'Product Code: * 3' and 'Revision: 1' are shown, along with 'SELECT' and 'UPDATE' buttons. A callout box points to the 'UPDATE' button with the text 'Select button'. Further down, 'Product Desc.: Example for Product Registration Confirmation', 'Container Size: Ballast', and 'Container Type: Ballast' are visible. A 'Step Number' field is set to '01', followed by a sequence of step buttons (STEP 1 to STEP 7, then red buttons). The 'Step Type' is set to 'Heating SV'. The 'PROCESS VESSEL' section includes 'Temperature' (Setpoint, Gradient), 'Rotor' (Speed, Position), and 'System Pressure' (Setpoint, Gradient) fields. The 'STORAGE VESSEL' section includes a 'Temperature' field. The 'MISC' section has 'Time' (Setpoint, Hold) and 'Programmable Contacts' (Contact #1 to #5). The 'STEP MANAGEMENT' section includes 'Source Step' (01), 'Destination Step' (32), and 'MOVE', 'COPY', and 'DELETE' buttons. The 'ICON^{SE}' logo is in the bottom left corner.

FIG 6.16

Step 2 – Confirmation of Update

- Select the Confirm button on the Update Confirmation screen



Update Confirmation

Please Confirm Recipe Update:


PRODUCT CODE: REVISION:

DATE & TIME:

Fig 6.17

Step 3 – Finished Update

- Update completed
- Revision number advanced to next number asterisk no longer visible in product code field



STOCK **Recipe Management Screen** Current User: MANAGER1
Thursday, April 10, 2003 1:30:47 PM

Product Code: Revision:

Product Desc.:

Container Size:

OVERVIEW **RECIPE MANAGEMENT** **RECIPE SETTINGS** **PROCESS TABLE** **RETORT** **TRENDS** **REPORTS** **ALARMS** **LOGIN**

STEP 1 **STEP 2** **STEP 3** **STEP 4** **STEP 5** **STEP 6** **STEP 7** **STEP 8** **STEP 9** **STEP 10** **STEP 11** **STEP 12** **STEP 13** **STEP 14** **STEP 15** **STEP 16** **STEP 17** **STEP 18** **STEP 19** **STEP 20**

Step Type

PROCESS VESSEL **STORAGE VESSEL**

Temperature: Setpoint Deg.F Gradient Deg.F **Rotor:** Speed RPM Position

System Pressure: Setpoint PSI Gradient PSI

MISC **STEP MANAGEMENT**

Time: Setpoint ☒ Hold :

Programmable Contacts: ☒ Contact #1 ☐ Contact #2 ☐ Contact #3 ☐ Contact #4 ☐ Contact #5

Source Step: **Destination Step:**

ICON^{SE}

Fig 6.18

f. Registering Recipes

General

- Registration of a new *Product code* is required after a new Recipe/Product code is completed
- The registration process places the New number in the SQL Server Database for future use

Step 1 - Registration of Recipe


- Select *Registration* button
- *Login* screen will appear, select a text field
- *Keyboard* screen will appear - Enter Password and User information (Fig 5.3)

The screenshot displays the 'Recipe Management Screen' with a sidebar on the left containing buttons: STOCK, OVERVIEW, RECIPE MANAGEMENT, RECIPE SETTINGS, PROCESS TABLE, RETORT, TRENDS, REPORTS, ALARMS, LOGIN, and ICON^{SE}. The main area includes a header with 'Current User: MANAGER1' and 'Thursday, April 10, 2003 12:33:17 PM'. Below this, there are input fields for 'Product Code' (with a red star icon and value '3'), 'Revision' (value '0'), 'Product Desc.' (value '0.000000'), 'Container Size' (value '0.000000'), and 'Container Type' (value '0.000000'). A 'SELECT' button is next to the Product Code field, and a 'REGISTER' button is next to the Container Type field. A callout box points to the 'REGISTER' button with the text: 'Select button to save New recipe number to the database'. Below these fields is a 'Step Number' field with the value '01'. A row of red buttons follows, with the first one labeled 'STEP 1'. Below this is a 'Step Type' dropdown menu set to 'Heating SV'. The screen is divided into three main sections: 'PROCESS VESSEL', 'STORAGE VESSEL', and 'STEP MANAGEMENT'. The 'PROCESS VESSEL' section includes 'Temperature' (Setpoint and Gradient fields, both with 'Deg.F' units), 'Rotor' (Speed and Position fields, with 'RPM' and 'Error' indicators), and 'System Pressure' (Setpoint and Gradient fields, both with 'PSI' units). The 'STORAGE VESSEL' section includes 'Temperature' (Setpoint field with '260.0 Deg.F' and a 'New Value' callout). The 'STEP MANAGEMENT' section includes 'Source Step' (value '1') and 'Destination Step' (value '32'), with 'MOVE', 'COPY', and 'DELETE' buttons. A 'MISC' section at the bottom left includes 'Time' (Setpoint and Hold fields) and 'Programmable Contacts' (Contact #1 through Contact #5).

Fig 6.19

Step 2 - Registration Confirmation

- Registration Confirmation - Fill out information necessary to identify the New Product Code
 - Select Confirm button
 - Prompt to **Please wait registration in progress...**



The image shows a 'Product Registration' dialog box with a blue title bar. It contains several input fields and two buttons. The fields are labeled 'NEW PRODUCT CODE:', 'PRODUCT DESCRIPTION:', 'NUMBER OF CONTAINERS:', 'CONTAINER SIZE:', and 'CONTAINER TYPE:'. The values entered are '3', 'Example for Product Registration Confirmation', '4', 'Ballast', and 'Ballast' respectively. At the bottom right are 'CONFIRM' and 'CANCEL' buttons. At the bottom left is a 'STOCK' button with a circular icon.

Field Label	Value
NEW PRODUCT CODE:	3
PRODUCT DESCRIPTION:	Example for Product Registration Confirmation
NUMBER OF CONTAINERS:	4
CONTAINER SIZE:	Ballast
CONTAINER TYPE:	Ballast

Buttons: CONFIRM, CANCEL, STOCK

Fig 6.20

g. Downloading Recipes

General

- The Downloading function places the Product Code in the HOST PC for use
- Retort will run the last Product Code downloaded

Step 1 - Downloading

- Select the Download button on the Recipe Management Screen
- Keyboard - screen will appear - Enter Password and User information (Fig5.3)

The screenshot shows the 'Recipe Management Screen' with a sidebar on the left containing buttons: STOCK, OVERVIEW, RECIPE MANAGEMENT, RECIPE SETTINGS, PROCESS TABLE, RETORT, TRENDS, REPORTS, ALARMS, LOGIN, and ICON^{SE}. The main area displays recipe details: Product Code (32767), Revision (7), Product Desc. (Test Recipe Created 02:13:03 by TS), Container Size (Ballast), and Container Type (Ballast). A 'SELECT' button is next to the Product Code. Below this is a 'Step Number' field set to 01, followed by a row of step indicators (STEP 1 to STEP 7, with STEP 1 highlighted in green). A 'Step Type' dropdown is set to 'Heating SV'. The 'PROCESS VESSEL' section includes Temperature (Setpoint, Gradient), Rotor (Speed, Position), and System Pressure (Setpoint, Gradient) fields. The 'STORAGE VESSEL' section includes Temperature (Setpoint) and a 'New Value' callout pointing to the 260.0 Deg.F setpoint. The 'MISC' section includes Time (Setpoint, Hold) and Programmable Contacts (Contact #1 to #5). The 'STEP MANAGEMENT' section includes Source Step (1), Destination Step (32), and buttons for MOVE, COPY, and DELETE. A 'DOWNLOAD' button is located on the right side of the screen, with a 'Select button' callout pointing to it.

Fig 6.21

Step 2 – Download Confirmation

- Download Confirmation screen will appear, fill in text as needed to identify
- Confirm – Select the button on the Download Confirmation screen
 - Prompt to Please wait download in progress...

The screenshot shows the 'Download Confirmation' screen with the title 'Please Confirm Recipe Download:'. It displays the same Product Code (32767) and Revision (7) as Fig 6.21. The 'DATE & TIME' is Thursday, April 10, 2003 11:42:43 AM. The 'COMMENTS' field contains the text 'download shot for user manual'. At the bottom are 'CONFIRM' and 'CANCEL' buttons. A 'Touch field to input text' callout points to the comments field, and a 'Select button' callout points to the CONFIRM button.

Fig 6.22

SECTION 7 - ICON^{SE} MODIFY PROCESS STEPS

a. Example Full Water Immersion Step Modification

Step 1 - Heating Storage Vessel (HSV) - Completed

- Enter Recipe Parameters and Recipe Steps for each Step Number of the Product Code using the procedure outlined in Section 6(b).

The screenshot displays the 'Recipe Management Screen' for 'Current User: MANAGER1' on 'Thursday, April 10, 2003 1:13:54 PM'. The interface includes a left sidebar with navigation buttons: STOCK, OVERVIEW, RECIPE MANAGEMENT (selected), RECIPE SETTINGS, PROCESS TABLE, RETORT, TRENDS, REPORTS, ALARMS, and LOGIN. The main area shows product details: Product Code: 3, Revision: 1, Product Desc.: Example for Product Registration Confirmation, Container Size: Ballast, and Container Type: Ballast. Below this, the 'Step Number' is set to 01. A table of steps is visible, with Step 1 highlighted. The 'Step Type' is 'Heating SV'. The 'PROCESS VESSEL' section includes Temperature (Setpoint, Gradient), Rotor (Speed, Position), and System Pressure (Setpoint, Gradient). The 'STORAGE VESSEL' section includes Temperature (Setpoint, Gradient). The 'MISC' section includes Time (Setpoint) and a 'Hold' checkbox. The 'STEP MANAGEMENT' section includes Source Step (01), Destination Step (32), and buttons for MOVE, COPY, and DELETE. Callouts identify various fields: 'Step Number' points to the step number field; 'Step Description' points to the step description field; 'New Value' points to the Storage Vessel Temperature Setpoint; 'Position of Cages' points to the Rotor Position field; 'System Pressure Set point / Gradient' points to the System Pressure Setpoint field; and 'Hold set for end step. See "Note" below' points to the Hold checkbox.

Fig 7.1

NOTE	
It is recommended that a "Hold" be placed in the last "Heating Storage Vessel (HSV)" step.	
If the recipe will require the operator to enter "Initial Temperature" (I.T.) it is not recommended that a "Hold" be included at the end of the last HSV step. Refer to "Recipe Settings" section for information on the "Recipe Settings" page.	

Step 2 - Sterilization 1 (S1) - Completed

- Retort Vent step - used to remove air and fill the retort to the desired level.
- Example of data needed for a typical Sterilization 1 step.
- To enter Recipe Parameters and Recipe Steps see Section 5b
 1. Select Step Number – Choose step to modify
 2. Select Step Type field – Choose desired description from list
 3. Select Speed – Set RPM (Usually 0 in S1)
 4. Select Rotor Position – Choose desired position from list (depends upon container)
 5. Select System Pressure Setpoint – 0 to 60 PSI
 6. Select System Pressure Gradient – Increase over the duration of the step
 7. Select Time Setpoint – This is the duration of the step expressed in **seconds**

STOCK **Recipe Management Screen** Current User: MANAGER1
Thursday, April 10, 2003 1:15:23 PM

Product Code: Revision: SELECT

Product Desc.: UPDATE

Container Size:

Container Type:

Step Number:

STEP 1 **STEP 2** STEP 3 STEP 4 STEP 5 STEP 6 STEP 7

Step Type:

PROCESS VESSEL

Temperature: Setpoint Deg.F
Gradient Deg.F

Rotor: Speed RPM
Position

System Pressure:
Setpoint PSI
Gradient PSI

STORAGE VESSEL

Temperature: Setpoint Deg.F

MISC

Time: Setpoint
☐ Hold :

Programmable Contacts:

☐ Contact #1
☐ Contact #2
☐ Contact #3
☐ Contact #4
☐ Contact #5

STEP MANAGEMENT

Source Step: MOVE

Destination Step: COPY

DELETE

ICON^{SE}

Fig 7.2

Completed Sterilization 1 Step

Step 3 - Sterilization 2 (S2) - Completed

- Defined as Retort Come Up Time
- Data needed for a typical Sterilization 2 (Retort Come-Up Time) step.
 1. Select Step Number – Choose step to modify
 2. Select Step Type field – Choose desired description from list
 3. Select Speed – Set RPM
 4. Select Rotor Position – Choose desired position from list
 5. Select Temperature Set Point – Set point for Processing Temperature or overshoot temperature during Come Up.
 6. Select Temperature Gradient – Increase in temperature per minute during the step
 7. Select System Pressure Setpoint – 0 to 60 PSI
 8. Select System Pressure Gradient – Increase in PSI per minute during the step
 9. Select Time Setpoint – This is the duration of the step expressed in seconds

STOCK **Recipe Management Screen** Current User: MANAGER1
Thursday, April 10, 2003 1:16:57 PM

Product Code: * 3 Revision: 1 SELECT

Product Desc.: Example for Product Registration Confirmation UPDATE

Container Size: Ballast

Container Type: Ballast

Step Number: 03

STEP 1 STEP 2 STEP 3 STEP 4 STEP 5 STEP 6 STEP 7

Step Type: Sterilization 2

PROCESS VESSEL

Temperature: Setpoint 250.0 Deg.F Gradient 0.0 Deg.F

System Pressure: Setpoint 30.0 PSI Gradient 0.0 PSI

STORAGE VESSEL

Temperature: Setpoint Deg.F

Rotor: Speed 0.0 RPM Position 'C'

MISC

Time: Setpoint 480 Hold 8 : 00

Programmable Contacts:

☐ Contact #1
☐ Contact #2
☐ Contact #3
☐ Contact #4
☐ Contact #5

STEP MANAGEMENT

Source Step: 01 MOVE

Destination Step: 32 COPY

DELETE

ICON^{SE}

Fig 7.3

Completed Sterilization 2 (S2) Step

Step 4 - Sterilization 3 (S3) - Completed

- Defined as Cook Phase of operation
- Modify the Following Control Points as per previous step.
- Data needed for a typical Sterilization 3 (Cook) step.
 1. Select Step Number – Choose step to modify
 2. Select Step Type Field – Choose desired description from list
 3. Select Speed – Set RPM
 4. Select Rotor Position – Choose desired position from list
 5. Select Temperature Set Point – Set point for Processing Temperature.
 6. Select Temperature Gradient – Increase in temperature per minute during the step
 7. Select System Pressure Set point – 0 to 60 PSI
 8. Select System Pressure Gradient – Increase in PSI per minute during the step
 9. Select Time Set point – This is the duration of the step expressed in seconds

STOCK **Recipe Management Screen** Current User: MANAGER1
Thursday, April 10, 2003 1:17:36 PM

Product Code: * 3 Revision: 1 SELECT

Product Desc.: Example for Product Registration Confirmation UPDATE

Container Size: Ballast

Container Type: Ballast

Step Number: 04

STEP 1 STEP 2 STEP 3 **STEP 4** STEP 6 STEP 7

Step Type: Sterilization 3

PROCESS VESSEL

Temperature: Setpoint 250.0 Deg.F Gradient 0.0 Deg.F

Rotor: Speed 14.0 RPM Position Horiz

SYSTEM PRESSURE

Setpoint 30.0 PSI Gradient 0.0 PSI

MISC

Time: Setpoint 360 Hold 6 : 00

Programmable Contacts:

☐ Contact #1
☐ Contact #2
☐ Contact #3
☐ Contact #4
☐ Contact #5

STEP MANAGEMENT

Source Step: 01 MOVE

Destination Step: 32 COPY

DELETE

Fig 7.4

Completed Sterilization 3 (S3) Step

Step 5 - Cooling 1 (C1) - Completed

- Defined as the phase of cooling use to recover some of the processing water to the Storage Vessel and the initial cooling phase.
- Not a timed phase
- Data needed for a typical Cool 1 (Cooling) step.
 1. Select Step Number – Choose step to modify
 2. Select Step Type Field – Choose desired description from list
 3. Select Speed – Set RPM
 4. Select Rotor Position – Choose desired position from list
 5. Select System Pressure Set Point – 0 to 60 PSI
 6. Select System Pressure Gradient – Increase or decrease in PSI during the step

STOCK **Recipe Management Screen** Current User: MANAGER1
Thursday, April 10, 2003 1:21:21 PM

Product Code: * 3 Revision: 1 SELECT
 Product Desc.: Example for Product Registration Confirmation UPDATE
 Container Size: Ballast
 Container Type: Ballast

Step Number: 05

STEP 1 STEP 2 STEP 3 STEP 4 STEP 5 STEP 6 STEP 7 STEP 8 STEP 9 STEP 10 STEP 11 STEP 12 STEP 13 STEP 14 STEP 15 STEP 16 STEP 17 STEP 18 STEP 19 STEP 20

Step Type: Cooling 1

PROCESS VESSEL

Temperature: Setpoint Deg.F Gradient Deg.F

Rotor: Speed 0.0 RPM Position 'B'

STORAGE VESSEL

Temperature: Setpoint Deg.F

System Pressure:

Setpoint 28.0 PSI

Gradient 0.0 PSI

MISC

Time: Setpoint Hold

Programmable Contacts:

☐ Contact #1
☐ Contact #2
☐ Contact #3
☐ Contact #4
☐ Contact #5

STEP MANAGEMENT

Source Step: 01 MOVE

Destination Step: 32 COPY

DELETE

ICON^{SE}

Fig 7.5

Completed Cooling 1 (C1) Step

Step 6 - Cooling 2 (C2) - Completed

- Defined as the final cooling phase pressure is usually ramped down in this phase as temperature is decreased.
- This phase is based on time as well as end temperature
- Data needed for a typical Cool2 (Cooling) step.
 1. Select Step Number – Choose step to modify
 2. Select Step Type Field – Choose desired description from list
 3. Select Speed – Set RPM
 4. Select Rotor Position – Choose desired position from list
 5. Select Temperature Set Point – Used to define the temperature at which the retort will go to drain phase.
 6. Select System Pressure Setpoint – 0 to 60 PSI
 7. Select Time Set point – This is the duration of the step expressed in seconds

STOCK **Recipe Management Screen** Current User: MANAGER1
Thursday, April 10, 2003 1:21:57 PM

Product Code: * 3 Revision: 1 SELECT
 Product Desc.: Example for Product Registration Confirmation UPDATE
 Container Size: Ballast
 Container Type: Ballast

Step Number: 06

STEP 1 STEP 2 STEP 3 STEP 4 STEP 5 **STEP 6** STEP 7

Step Type: Cooling 2

PROCESS VESSEL **STORAGE VESSEL**

Temperature: Setpoint 100.0 Deg.F Rotor: Speed 0.0 RPM Temperature: Setpoint 0.0 Deg.F
 Gradient 0.0 Deg.F Position 'B'

System Pressure: Setpoint 26.0 PSI
 Gradient 0.0 PSI

MISC **Programmable Contacts:** **STEP MANAGEMENT**

Time: Setpoint 180
☐ Hold 3 : 00

Contact #1
 Contact #2
 Contact #3
 Contact #4
 Contact #5

Source Step: 01
 Destination Step: 32

MOVE
COPY
DELETE

ICON^{SE}

Fig 7.6

Completed Cooling 2 (C2) Step

Step 7 – Drain - Completed

- Defined as the emptying of water from the retort
- Phase duration is based on time
- Data needed for a typical Cool2 (Cooling) step.
 1. Select Step Number – Choose step to modify
 2. Select Step Type Field – Choose desired description from list
 3. Select Speed – Set RPM - Usually to Zero (0)
 4. Select Rotor Position – Choose desired position from list
 5. Select Time Set point – This is the duration of the step expressed in seconds
 6. Select Storage Vessel Set point – This is the temperature the Storage Vessel will preheat to in Drain step

STOCK **Recipe Management Screen** Current User: MANAGER1
Thursday, April 10, 2003 1:22:20 PM

Product Code: * 3 Revision: 1 SELECT

Product Desc.: Example for Product Registration Confirmation UPDATE

Container Size: Ballast

Container Type: Ballast

Step Number: 07

STEP 1 STEP 2 STEP 3 STEP 4 STEP 5 STEP 6 STEP 7 1

Step Type: Drain 2

PROCESS VESSEL

Temperature: Setpoint Deg.F Gradient Deg.F

Rotor: Speed 0.0 RPM Position Horiz 3 4

STORAGE VESSEL 6

Temperature: Setpoint 220.0 Deg.F

System Pressure:

Setpoint 24.0 PSI Gradient 0.0 PSI

MISC

Time: Setpoint 180 5

Hold 3 : 00

Programmable Contacts:

☐ Contact #1
☐ Contact #2
☐ Contact #3
☐ Contact #4
☐ Contact #5

STEP MANAGEMENT

Source Step: 01

Destination Step: 32

MOVE
COPY
DELETE

ICON^{SE}

Fig 7.7

Completed Drain Step

Step 8 - Process Table Modification – Completed

- Tables are modified with the data supplied by a **Process Authority**
- All entries are made by selecting the corresponding field and manually entering Using Keypad.
- **DO NOT CHANGE TABLES WITHOUT THE AUTHORIZATION OF STOCK America Inc. or Process Authority.**

Custom Table Settings

Current User: MANAGER1

Thursday, April 10, 2003 1:23:06 PM

OVERVIEW

RECIPE
MANAGEMENT

RECIPE
SETTINGS

PROCESS
TABLE

RETORT

TRENDS

REPORTS

ALARMS

LOGIN

ICON^{SE}

Custom Process Table

Process Vessel Temperature										
I.T.	246.0	248.0	250.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
45.0	420	390	360	0	0	0	0	0	0	0
50.0	380	365	340	0	0	0	0	0	0	0
55.0	330	325	320	0	0	0	0	0	0	0
0.0	0	0	0	0	0	0	0	0	0	0
0.0	0	0	0	0	0	0	0	0	0	0

Note: Times are entered in Seconds.

Fig 7.8

Step 9 - Update Recipe - See Section 6(e) for procedure

Step 10 - Register Recipe - See Section 6(f) for procedure

SECTION 8 - RUNNING A PROCESS

a. General

- See START UP & LOGIN PROCEDURE – See SECTION 3 – Login as operator or manager

b. Example Full Water Immersion Process

- This is an example of a process that assumes there is a recipe loaded and ready to run. See Section 6(b) to Load a recipe.
- The Retort Screen is used throughout the operation of a normal process run.

Color Key	Function
Red	Indicates that the item is not active or on
Green	Indicates that the item is active or on
Yellow	Water Level

Starting the Process

- STEP1 - Go to the “RETORT” screen and Select the “START” button.




Fig 8.1

NOTE: Product Number will not change on screen until Start button is selected

- STEP 2 – User Name and Password are required
- STEP 3 – Enter the cook number by use of key pad screen. (Fig 5.4)
 - Enter a Cook Number (valid range is 1 through 32767).
- STEP 4 – Select the “YES” button to confirm starting the cook.

Start Confirmation

Start of Cook:

PRODUCT CODE: 995 REVISION: 9

DATE & TIME: Sunday, April 13, 2003 1:02:22 PM

COOK NUMBER:

YES NO

STOCK

Fig 8.2

NOTE	
It is the responsibility of the operator to verify that the Product Code entered corresponds to the Product being processed	
Cook number = Maximum of 5 digits long should always be assigned.	
Product Code and Revision Number will update once the <u>Start</u> button is selected	

Heating Storage Vessel (HSV) ≤ 212 Deg F - No Pressure Control

- HSV Step in progress, Storage Vessel (**SV**) temperature ≤ 212 Deg F
- No Storage Vessel Pressure control is used in this step, **SV** vent valve is 100% open
- Analog valves and level indicators indicate the % open on the display
- Digital Valves and motors are on or off




Fig 8.3

Button	Function
PAUSE	Stops the process and puts valves and pumps in off position. Stops accumulated time
HOLD	Keeps process in current step in definitely
ABORT	Stops process completely

Screen Display for HSV	Description	Status
SV STEAM	Digital - Steam to preheat Storage Vessel	Icon is green (on)
SV VENT	Analog - Storage Vessel Vent	Shows actual % open
STORAGE VESSEL Level	Digital - Water Level Sensor	Sensor is green (on)
STORAGE VESSEL Fill Valve	Manual - Fills SV with Cold Water	-
PROCESS VESSEL Level	Analog - Water Level Sensor	Shows actual %
Rotor Horizontal	Rotor is in horizontal position	Sensor is green (on)
Steam Supply OK	Steam supply is adequate	Sensor is green (on)
Air Supply OK	Air is adequate	Sensor is green (on)
Door OK	Door safety switch is engaged	Sensor is green (on)
Set Points & Actual	Shown for Time , Pressure and Temperature	-

Heating Storage Vessel (HSV) ≥ 212 Deg F – Pressure Control

- HSV Step in progress, Storage vessel ≥ 212 Deg F
- Storage Vessel is pressure controlled in this portion of HSV




Fig 8.4

Display for HSV Pressure Control	Description	Status
SV STEAM	Digital - Steam to preheat Storage Vessel	Icon is green (on)
SYS PRESS	System Pressure Regulation Valve	Shows % open
STORAGE VESSEL Level	Digital - Water Level Sensor	Sensor is green (on)
Rotor Horizontal	Digital - Rotor is in horizontal position	Sensor is green (on)
Steam Supply OK	Digital - Steam supply is adequate	Sensor is green (on)
Air Supply OK	Digital - Air is adequate	Sensor is green (on)
Door OK	Digital - Door safety switch is engaged	Sensor is green (on)
Set Points & Actual	Shown for Time , Pressure and Temperature	-

Heating Storage Vessel End - Prompt for IT

- If entry of an Initial Temperature is set in Recipe Settings, a button will appear on MAIN MENU for entering the INITIAL TEMP value before process can begin.
- STEP1 - Select the INITIAL TEMP button.




Fig 8.5

- STEP – 2 Operator will be prompted for user name and password, enter on Keyboard (Fig 5.2)
- STEP – 3 Enter the product Initial Temperature on keypad and Select enter (Fig 5.3)
- STEP – 4 Select YES button on IT Confirmation to accept the entry. (Fig. 5.18)

The screenshot shows the 'IT Confirmation' dialog box. It has a title bar 'IT Confirmation' and a main title 'Please Enter Initial Temperature:'. Below the title, there are fields for 'PRODUCT CODE: 995', 'REVISION: 9', 'DATE & TIME: Friday, February 14, 2003 10:41:49 AM', and 'INITIAL TEMP.: 45.0'. At the bottom, there are 'YES' and 'NO' buttons. The 'STOCK' button is visible at the very bottom of the dialog.

(Fig 8.6)

Sterilization 1 - In Progress

- Process is now in operation and the retort is in Vent.




Fig 8.6

Display for Sterilization I	Description	Status
SYS Press SV	Analog - System pressure Valve Storage Vessel	Shows % open
PV Vent	Digital - Process Vessel Vent	Icon is green (on)
Throttle Flap	Digital - Throttle Flap Valve	Icon is green (on)
Connection	Digital - Connector Valve	Icon is green (on)
Circulation Pump	Digital - Circulation Pump	Icon is green (on)
Level	Water Level	Shows % open
Rotor "B" Position	Digital - Rotor is in custom location "B"	Icon is green (on)
Steam Supply OK	Digital - Steam supply is adequate	Icon is green (on)
Air Supply OK	Digital - Air is adequate	Icon is green (on)
Flow OK	Digital - Flow of water is adequate	Icon is green (on)
Door OK	Digital - Door safety switch is engaged	Icon is green (on)
Sterilization I	Current step is Sterilization 1 (Vent)	-
Set Points & Actual	Shown for Time , Pressure and Temperature	Current status

Sterilization 2 - In Progress

- Sterilization 2 is used to bring the Process Vessel up to set point temperature, pressure and rotation.




Fig 8.8

Display for SII	Description	Status
SYS Press SV	Analog - System pressure Valve Storage Vessel	Shows % open
Process Vessel Steam	Analog - Process Vessel Heating Valve is on	Shows % open
Throttle Flap	Digital - Throttle Flap Valve	Icon is green (on)
Connection	Digital - Connector Valve	Icon is green (on)
Circulation Pump	Digital - Circulation Pump	Icon is green (on)
Level	Water Level	Shows % open
Rotor Horizontal	Digital - Rotor is in horizontal	Icon is green (on)
Steam Supply OK	Digital - Steam supply is adequate	Icon is green (on)
Air Supply OK	Digital - Air is adequate	Icon is green (on)
Flow OK	Digital - Flow of water is adequate	Icon is green (on)
Door OK	Digital - Door safety switch is engaged	Icon is green (on)
Sterilization II	Current step is Sterilization II (Come Up)	-
Set Points & Actual	Shown for Time , Pressure and Temperature	Current status

Sterilization 3 - In Progress

- Process is now in cook phase and the retort is at process temperature.
- During S3, if User Inputs are required, a button will appear to enter the inputs. (Fig 5.24)
- Press the USER INPUT button.





Fig 8.9

Display for SIII	Description	Status
SYS Press SV	Analog - System pressure Valve Storage Vessel	Shows % open
Process Vessel Steam	Analog - Process Vessel Heating Valve is on	Shows % open
Throttle Flap	Digital - Throttle Flap Valve	Icon is green (on)
Connection	Digital - Connector Valve	Icon is green (on)
Circulation Pump	Digital - Circulation Pump	Icon is green (on)
Process Vessel Level	Analog - Water Level in Process Vessel	Shows % open
Rotor "B" Position	Digital - Rotor is in custom location "B"	Icon is green (on)
Brake off	Rotor motor brake is off and motor is on	Icon is green (on)
Steam Supply OK	Digital - Steam supply is adequate	Icon is green (on)
Air Supply OK	Digital - Air is adequate	Icon is green (on)
Flow OK	Digital - Flow of water is adequate	Icon is green (on)
Door OK	Digital - Door safety switch is engaged	Icon is green (on)
Sterilization III	Current step is Sterilization III (Cook)	-
Set Points & Actual	Shown for Time , Pressure and Temperature	Current status

Sterilization 3 - In Progress – User Inputs

- User Input Confirmation will appear. (Fig 5.24)
- User Name and Password are required.
- After completing User Input entries, Select the Confirm button.




The dialog box is titled "User Input Confirmation". It contains a header "Please Provide The Required User Input:". Below this, there are four input fields: "MIG TEMP:" with value "250.4", "SYSTEM PRESSURE:" with value "32.9", "CHART TEMP:" with value "250.2", and "ROTOR RPM:" with value "14". At the bottom left, there is a "PV LEVEL" section with "OK" and "NOT OK" options, where "X" is selected under "OK". To the right of this are "CONFIRM" and "CANCEL" buttons. At the very bottom, there is a "STOCK" button.

Fig 8.10

Button	Function
Confirm	Allows data to be entered into the recipe
Cancel	Exits Screen

- Input Validation screen will appear after completing User Input entries, if entries are correct. Select the Yes button. Fig 5.28



The dialog box is titled "Input Validation:". It contains the text "Please validate the following inputs:". Below this, there is a list of inputs and their values: "MIG Temp.: 250", "Chart Temp.: 250", "System Press.: 32", "Rotor RPM: 0", and "PV Level: OK". At the bottom, there are "Yes" and "No" buttons.

LOW INITIAL TEMPERATURE or RETORT TEMPERATURE

If I.T. or R.T. information for a particular retort batch is below the minimum tolerances provided in the table, or the temperatures for the MIG are LOWER than the temperature for the Chart, the ICON^{SE} Retort PC will activate an alarm. At the end of the run the corresponding alarm message documenting the deviation will be noted on the Sterilization Record. Consult with your process authority for a proper procedure to use in the event of a low R.T. or low I.T. deviation.

Cool 1 - In Progress

- Used to recover hot water to the Storage Vessel.
- System Pressure is controlled in the Storage Vessel.
- Valve changes and pump output changes will be noted on the screen.




Fig 8.11

Display for Cool I	Description	Status
SYS Press SV	Analog - System pressure Valve Storage Vessel	Shows % open
SV Vent	Analog - Storage Vessel Pressure Vent	Shows % open
Cold Water Valve	Digital - Cold Water Supply Valve	Icon is green (on)
Cold Water Pump	Digital - Cold water booster pump	Icon is green (on)
Throttle Flap	Digital - Throttle Flap Valve	Icon is green (on)
Connection	Digital - Connector between Storage & Process Vessel	Icon is green (on)
Circulation Pump	Digital - Circulation Pump	Icon is green (on)
Process Vessel Level	Analog - Water Level in Process Vessel	Shows % open
Rotor "B" Position	Digital - Rotor is in custom location "B"	Icon is green (on)
Steam Supply OK	Digital - Steam supply is adequate	Icon is green (on)
Air Supply OK	Digital - Air is adequate	Icon is green (on)
Flow OK	Digital - Flow of water is adequate	Icon is green (on)
Door OK	Digital - Door safety switch is engaged	Icon is green (on)
Cool 1	Current step is Cool1 – Recover process water to storage vessel	-
Set Points & Actual	Shown for Time , Pressure and Temperature	

Cool 2 - In Progress

- Storage Vessel is full and now water diverts to drain
- Connection valve closes and valve outputs change.
- Other operational changes will be noted.




Fig 8.12

Display for Cool II	Description	Status
SYS Press SV	Analog - System pressure Valve Storage Vessel	Shows % open
Storage Vessel Level	Water level in the storage vessel	Icon is green (on) Full
Cold Water Valve	Digital - Cold Water Supply Valve	Icon is green (on)
Cold Water Pump	Digital - Cold water booster pump	Icon is green (on)
Throttle Flap	Digital - Throttle Flap Valve	Icon is green (on)
Drain	Analog - Drain Valve	Icon is green (on)
Circulation Pump	Digital - Circulation Pump	Icon is green (on)
Process Vessel Level	Analog - Water Level in Process Vessel	Shows % open
Steam Supply OK	Digital - Steam supply is adequate	Icon is green (on)
Air Supply OK	Digital - Air is adequate	Icon is green (on)
Flow OK	Digital - Flow of water is adequate	Icon is green (on)
Door OK	Digital - Door safety switch is engaged	Icon is green (on)
Cool II	Current step is Cool II	-
Set Points & Actual	Shown for Time , Pressure and Temperature	

Drain - In Progress

- Cooling is completed; the retort has reached the setpoint temperature.
- Drain opens and Storage Vessel begins heating
- Valves change to off and pump outputs change.




Fig 8.13

Display for Drain	Description	Status
SYS Press SV	Analog - System pressure Valve Storage Vessel	Shows % open
Storage Vessel Level	Digital - Water level in the storage vessel	Icon is green (on) Full
PV Vent	Digital - Process Vessel Vent	Icon is green (on)
Drain	Analog - Drain Valve	Shows % open
Circulation Pump	Digital - Circulation Pump	Icon is green (on)
Process Vessel Level	Analog - Water Level in Process Vessel	Shows % open
Rotor Horizontal	Digital - Rotor is in horizontal Unload position	Icon is green (on)
Steam Supply OK	Digital - Steam supply is adequate	Icon is green (on)
Air Supply OK	Digital - Air is adequate	Icon is green (on)
Flow OK	Digital - Flow of water is adequate	Icon is green (on)
Door OK	Digital - Door safety switch is engaged	Icon is green (on)
Drain	Current step is Drain	-
Set Points & Actual	Shown for Time , Pressure and Temperature	

Process Pause - In Progress

- Pausing the process stops the cook in the current step, turning off all control output devices and stopping the accumulated step time.
- Valve & Pump outputs change to off.
- Storage Vessel vent modulates to maintain pressure control
- When the process is in *PAUSE*, you can go forward or backward step-by-step in the process using the *Previous Step* or *Next Step* buttons.
- Select *Remove Pause* button to start process again. Prompt for user name and password will appear




Fig 8.13

Display for Pause	Description	Status
SV Vent	Analog - Storage Vessel Vent Opens	Shows % open
Storage Vessel Level	Digital - Water level in the storage vessel	Icon is green (on) Full
Process Vessel Level	Analog - Water Level in Process Vessel	Shows % open
Rotor Horizontal	Digital - Rotor is in horizontal position	Icon is green (on)
Steam Supply OK	Digital - Steam supply is adequate	Icon is green (on)
Air Supply OK	Digital - Air is adequate	Icon is green (on)
Door OK	Digital - Door safety switch is engaged	Icon is green (on)
Set Points & Actual	Shown for Time , Pressure and Temperature	

Process Hold - In Progress

- Holding the process keeps the cook in the current step
- Accumulated step time continues to run.
- Valves, pumps and other outputs remain in the run position.




Fig 8.14

Display for Hold	Description	Status
SYS Press SV	Analog - System pressure Storage Vessel	Shows % open
Process Vessel Level	Digital - Water Level in Process Vessel	Shows % open
Connection	Digital - Connector Valve	Icon is green (on)
Throttle Flap	Digital - Throttle Flap Valve	Icon is green (on)
Process Vessel Steam	Analog - Process Vessel Heating Valve is on	Shows % open
Circulation Pump	Digital - Circulation Pump	Icon is green (on)
Rotor C Position	Digital - Rotor is in custom position	Icon is green (on)
Steam Supply OK	Digital - Steam supply is adequate	Icon is green (on)
Air Supply OK	Digital - Air is adequate	Icon is green (on)
Flow OK	Digital - Flow of water is adequate	Icon is green (on)
Door OK	Digital - Door safety switch is engaged	Icon is green (on)
Set Points & Actual	Shown for Time , Pressure and Temperature	

Remove Process Hold - In Progress

- Select Remove Hold button on Retort Screen when ready to continue process steps again. (Fig 8.14)
- Prompts for User name and Password will appear and must be entered on Keyboard before process will continue (Fig 5.3)
- Remove Hold Confirmation will appear Select the Yes button




Fig 8.15

Field or Button	Function
Yes	Allows process to continue from point of hold and finish any remaining time in the step
No	Keeps the process in the current step
Reason	Dialog box for explanation; touch field to call up key board

Trends – Viewing

General

- Selected parameters can be viewed in real time at any point during the process.

Select Trends Option

- Trends* – Select button on *Main Menu* at left hand column of *Retort* screen.




Fig 8.16

View Trending In Progress

- Trending Screen will appear.
 - Select the desired line at the point you want to view and a value will appear.
 - To view actual current value see data at the bottom of screen




Fig 8.17

Appendix IV: Retort Shipment Information

Retort Shipment to SOPAKCO: May 2002

Stock 1100 Retort SERIAL #:64026

Control Cabinet with PLC 5/10 controller with following modules:

- ❑ Power Module
- ❑ DC Input Module
- ❑ DC Output Module
- ❑ Analog Input Module
- ❑ Analog Output Module

XYCOM COMPUTER with

- ❑ Network Card
- ❑ AB KT Card

Backup Power Supply

Oxidata Printer

Woods Variable Frequency Drive controller, 5 HP, 230 V, 3 PH

Quick Disconnect Power Cable

Quick Disconnect Low Power and Signal Cable

Retort process vessel and storage vessel with all control valves, pumps and piping including:

- SV level gauge
- Pressure Safety Valves (2)
- Pressure Transmitters (2)
- Strobe Light
- Rotor Proximity Switches (3)
- Level Gage PV with sight glass
- Anderson DART serial#: 9826326
- Accutech RTD PV
- Steam Pressure Alarm Switch
- Minco RTD SV
- Taylor Chart Recorder
- MIG

Retort crates (8)

Dollies (8)

Dolly Track

Retort Racks for Polymeric Tray (96)

Retort Plates (5)

Pipe Wrench plus bar

Man Hole Cover

Mosol Water Conditioner

The following manuals and misc items were shipped with the retort:

Xycom manual and disks

DOS User guide and disk

Touch screen Driver manual and disk

Monitor Mouse Manual and Disk
Two fuses
Anderson Manual and Certificate
Woods VFD Manual
Electrical Drawing
Installation Qualification Document
QEMM software
Stock Manuals (3)
ICON2000 Operator Manual
Chart Recorder Manual
Chart Recorder Charts (1 box)
Ink bottles for Chart Recorder
Woods Box:

 Pulleys, bolts and split ring

Parts Box

 Lift handle
 Yellow Locking Bracket
 Rotor Extracting Tools
 Bolts
 Brash Valve
 Grease Cartridge 2, #0900160
 Silicon Paste, #0901010
 Viscogen kl 130, #0900250
 Seal Kit #1002063
 Seal Kit #1002066
 Seal Kit #1002067
 Break pins (5), #1000091

Retort Shipment to SOPAKCO: April 2003

Shipping Address: 320 South Broad Street, Bennettsville, SC

Stock 1100 Retorts with ICON 2000 version 4 control system
Serial Number 39883

Control Cabinet with SLC505 controller with following modules:

- ☐ Analog Input (1)
- ☐ Analog Output (2)
- ☐ DC Input (2)
- ☐ DC Output (2)

Allen Bradley Model 6181 Computer with following licensed software and hardware options:

- ☐ Windows 2000 Professional Operating System
- ☐ Microsoft Office 2000 Pro
- ☐ Microsoft SQL Server 2000 Personal Edition
- ☐ RS View SE Client
- ☐ RS View SE Server 25
- ☐ RS Linx for RS View
- ☐ RS SQL Professional 1500
- ☐ ICON 2000 version 4 software application
- ☐ HDD: 76.6 GB
- ☐ Processor: Pentium III
- ☐ Memory: 256 MB
- ☐ DVD
- ☐ 3.5" Floppy Drive
- ☐ I/O cards (2)
- ☐ UPS

Retorts process vessel and storage vessel with all control valves, pumps and piping including:

- ☐ SV level gauge
- ☐ Pressure Safety Valves (2)
- ☐ Ascroft Pressure Transmitter SV (0-100 psig range)
- ☐ LogTec Pressure Transmitter PV (0-60 psig)
- ☐ Strobe Light
- ☐ Rotor Proximity Switches (3)
- ☐ Endress & Hauser Analog Level Gauge PV with Sight Glass
- ☐ Minco Temperature Transmitters (2)
- ☐ Steam Pressure Alarm Switch
- ☐ ABB Kent Taylor Fullscope ER/C Chart Recorder with one box of charts
- ☐ MIG with Hub
- ☐ Temperature Gauge SV
- ☐ Pressure Gauge PV
- ☐ ES Mode Valves
- ☐ Analog Drain Valve

Retort Crates with Bottom Plates (8):

Dolies (8)

Dolly Track

Top Plate Lift Handle

Retort Rigging Lift Hook (1per two retorts)

Retort Racks (0)

Documentation:

- ☐ Installation Validation Report
- ☐ Operation Manual
- ☐ Electrical Drawings
- ☐ Instruction Manual Chart Recorder

Retort Shipment to SOPAKCO: April 2003

Shipping Address: 320 South Broad Street, Bennettsville, SC

Stock 1100 Retorts with ICON 2000 version 4 control system
Serial Number 39992

Control Cabinet with SLC505 controller with following modules:

- ☐ Analog Input (1)
- ☐ Analog Output (2)
- ☐ DC Input (2)
- ☐ DC Output (2)

Allen Bradley Model 6181 Computer with following licensed software and hardware options:

- ☐ Windows 2000 Professional Operating System
- ☐ Microsoft Office 2000 Pro
- ☐ Microsoft SQL Server 2000 Personal Edition
- ☐ RS View SE Client
- ☐ RS View SE Server 25
- ☐ RS Linx for RS View
- ☐ RS SQL Professional 1500
- ☐ ICON 2000 version 4 software application
- ☐ HDD: 76.6 GB
- ☐ Processor: Pentium III
- ☐ Memory: 256 MB
- ☐ DVD
- ☐ 3.5" Floppy Drive
- ☐ I/O cards (2)
- ☐ UPS

Retorts process vessel and storage vessel with all control valves, pumps and piping including:

- ☐ SV level gauge
- ☐ Pressure Safety Valves (2)
- ☐ Ascroft Pressure Transmitter SV (0-100 psig range)
- ☐ LogTec Pressure Transmitter PV (0-60 psig)
- ☐ Strobe Light
- ☐ Rotor Proximity Switches (3)
- ☐ Endress & Hauser Analog Level Gauge PV with Sight Glass
- ☐ Minco Temperature Transmitters (2)
- ☐ Steam Pressure Alarm Switch
- ☐ ABB Kent Taylor Fullscope ER/C Chart Recorder with one box of charts
- ☐ MIG with Hub
- ☐ Temperature Gauge SV
- ☐ Pressure Gauge PV
- ☐ ES Mode Valves
- ☐ Analog Drain Valve

Retort Crates with Bottom Plates (8):

Dolies (8)

Dolly Track

Top Plate Lift Handle

Retort Rigging Lift Hook (1per two retorts)

Retort Racks (0)

Documentation:

- ☐ Installation Validation Report
- ☐ Operation Manual
- ☐ Electrical Drawings
- ☐ Instruction Manual Chart Recorder

Retort Shipment to SOPAKCO: April 2004

Shipping Address: 320 South Broad Street, Bennettsville, SC

Stock 1100 Retorts with ICON 2000 version 4 control system
Serial Number 39882

Control Cabinet with SLC505 controller with following modules:

- ☐ Analog Input (1)
- ☐ Analog Output (2)
- ☐ DC Input (2)
- ☐ DC Output (2)
- ☐ SLC-IP address: 208.211.240.183

Computer Dynamics PAC-OP Operator Interface (M930100184) (<http://www.cdynamics.com/pacop.html>) with following licensed software and hardware options:

- ☐ Windows 2000 Professional Operating System
- ☐ Microsoft Office XP-SBE
- ☐ Microsoft SQL Server 2000 Personal Edition
- ☐ RS View SE Client
- ☐ RS View SE Server 25
- ☐ RS Linx for RS View
- ☐ RS SQL Standard 1500
- ☐ ICON 2000 version 4 software application
- ☐ HDD: 18.6 GB
- ☐ Processor: Pentium III
- ☐ Memory: 515 MB
- ☐ DVD/CD-ROM
- ☐ 3.5" Floppy Drive
- ☐ I/O cards (2)
- ☐ UPS
- ☐ PC-IP Address: 208.211.240.182, Computer Name: PC882 , Workgroup/Domain: Workgroup

Retorts process vessel and storage vessel with all control valves, pumps and piping including:

- ☐ SV level gauge
- ☐ Pressure Safety Valves (2)
- ☐ Ascroft Pressure Transmitter SV (0-100 psig range)
- ☐ LogTec Pressure Transmitter PV (0-60 psig)
- ☐ Strobe Light
- ☐ Rotor Proximity Switches (3)
- ☐ Endress & Hauser Analog Level Gauge PV with Sight Glass
- ☐ Minco Temperature Transmitters (2)
- ☐ Steam Pressure Alarm Switch
- ☐ ABB Kent Taylor Fullscope ER/C Chart Recorder with one box of charts
- ☐ MIG with Hub
- ☐ Temperature Gauge SV
- ☐ Pressure Gauge PV
- ☐ ES Mode Valves
- ☐ Analog Drain Valve

Retort Rigging Lift Hook (1per two retorts)

Documentation:

- ☐ Installation Validation Report
- ☐ Operation Manual
- ☐ Electrical Drawings
- ☐ Instruction Manual Chart Recorder

Retort Shipment to SOPAKCO: April 2004

Shipping Address: 320 South Broad Street, Bennettsville, SC

Stock 1100 Retorts with ICON 2000 version 4 control system
Serial Number 39993

Control Cabinet with SLC505 controller with following modules:

- ☐ Analog Input (1)
- ☐ Analog Output (2)
- ☐ DC Input (2)
- ☐ DC Output (2)
- ☐ SLC-IP address: 208.211.240.192

Computer Dynamics PAC-OP Operator Interface (M930100190) with following licensed software and hardware options:

- ☐ Windows 2000 Professional Operating System
- ☐ Microsoft Office XP-SBE
- ☐ Microsoft SQL Server 2000 Personal Edition
- ☐ RS View SE Client
- ☐ RS View SE Server 25
- ☐ RS Linx for RS View
- ☐ RS SQL Standard 1500
- ☐ ICON 2000 version 4 software application
- ☐ HDD: 18.6 GB
- ☐ Processor: Pentium III
- ☐ Memory: 515 MB
- ☐ DVD/CD-ROM
- ☐ 3.5" Floppy Drive
- ☐ I/O cards (2)
- ☐ UPS
- ☐ PC-IP Address: 208.211.240.193, Computer Name: PC993 , Workgroup/Domain: Workgroup

Retorts process vessel and storage vessel with all control valves, pumps and piping including:

- ☐ SV level gauge
- ☐ Pressure Safety Valves (2)
- ☐ Ascroft Pressure Transmitter SV (0-100 psig range)
- ☐ LogTec Pressure Transmitter PV (0-60 psig)
- ☐ Strobe Light
- ☐ Rotor Proximity Switches (3)
- ☐ Endress & Hauser Analog Level Gauge PV with Sight Glass
- ☐ Minco Temperature Transmitters (2)
- ☐ Steam Pressure Alarm Switch
- ☐ ABB Kent Taylor Fullscope ER/C Chart Recorder with one box of charts
- ☐ MIG with Hub
- ☐ Temperature Gauge SV
- ☐ Pressure Gauge PV
- ☐ ES Mode Valves
- ☐ Analog Drain Valve

Retort Rigging Lift Hook (1per two retorts)

Documentation:

- ☐ Installation Validation Report
- ☐ Operation Manual
- ☐ Electrical Drawings
- ☐ Instruction Manual Chart Recorder

Software Licenses that were shipped with retorts that have the ICON-SE control system:

Host Computer:

- ❑ Microsoft 2000 Server 5.00.2195 SP2, key VRPQX-CMD48-WB74X-2YKWQ-MXHW8, License# 51876-OEM-0005045-20563
- ❑ Microsoft 2000 Professional BHY7Q-PDDTX-HJWW7-06CX9-KJMW8 (second label on PC???)
- ❑ RSView SE Client Rev 2.10.00 ser # 2524000449 9701VWSCWAENE
- ❑ RSView SE Server 100 Rev 2.00.01 ser# 2527000280 9701VWSS100AENE
- ❑ RSSQL Standard 5000 Rev 5.00.00 ser# 2562000121 9356STD2350
- ❑ RSMACC Ver 1.01.00 ser# 2418000104, 9515-MACCCD-10.16.02 (not installed)
- ❑ Microsoft Office 2000 SBE, lic#: 54188-OEM-1792691-89839 (no CD existing)
- ❑ Microsoft SQL Server 2000 Standard SP2 BHD87-9R9XR-97KFF-PTWVP-K7P3M

Retort 883

- ❑ Microsoft 2000 Professional, Version 5.00 2195 SP 3, key FC9FD-9DRGV-GX4X7-FJPD8-VRMQJ, License # 51837-OEM-0009955-23195
- ❑ RSView SE Client Rev 2.10.00 ser # 2524001131 , 9701VWSCWAENE
- ❑ RSView SE Server 25 Rev 2.00.01 ser# 2526000236, 9701VWSS025AENE
- ❑ RSSQL Professional 1500 Rev 5.00.00 ser# 1131000765,
- ❑ Microsoft Office XP 2000 SBE, DWMD4-4YYHR-BDRGJ-6J2WF-TC2J
- ❑ Microsoft SQL Server 2000 Personal Edition, F7769-PCT2R-9MP4C-2HCWG-DQJBT
- ❑ Microsoft Internet Explorer, Version 6.0.2800.1106, SP 1

Retort 992

- ❑ Microsoft 2000 Profesional, Version 5.00 2195 SP 3, key MHM4D-HPJK2-KVXMB-HQQVY-8MYQG, License # 51837-OEM-0009955-23194
- ❑ RSView SE Client Rev 2.10.00 ser # 2524000448, 9701VWSCWAENE
- ❑ RSView SE Server 25 Rev 2.00.01 ser# 2526000235, 9701VWSS025AENE
- ❑ RSSQL Professional 1500 Rev 5.00.00 ser# 1131000766, 9356PRO2300
- ❑ Microsoft Office XP 2000 SBE, QT343-8H63D-CGMMQ-2VDR4-8KXF6
- ❑ Microsoft SQL Server 2000 Personal Edition, QXC83-XVKDY-KCPH3-K4YRF-FCX73
- ❑ Microsoft Internet Explorer, Version 6.0.2800.1106, SP 1

Retort 882 (PC#M930100184)

- ❑ Microsoft 2000 Professional, Version 5.00 2195, SP2, key THJRC-MPBJV-VWP4W-4PTJY-298JM, License #
- ❑ View SE Client Rev 3.00.01 ser # 2524002405 , cat#: 9701VWSCWAENE
- ❑ RSView SE Server 25 Rev 3.00.01 ser# 2526000889, cat#: 9701VWSS025AENE
- ❑ RSSQL Standard 1500 Rev 6.00.02 ser# 1126000556, cat#: 9356STD2300
- ❑ Microsoft Office XP SBE, VDPTM-7HF9H-WR64P-R7FHR-TVT63
- ❑ Microsoft SQL Server 2000 Personal Edition, SP-3a B4X86-JGK67-FTFQJ-VKRKG-DXMMT

Retort 993 (PC#M930100190)

- ❑ Microsoft 2000 Professional, Version 5.00 2195, SP2, key FYP96-KHDWT-HB8J9-MDBJX-Y2DJ, License # 51873-OEM-0011577-07407
- ❑ RSView SE Client Rev 3.00.01 ser # 2524002406, cat#: 9701VWSCWAENE
- ❑ RSView SE Server 25 Rev 3.00.01 ser# 2526000890, cat#: 9701VWSS025AENE
- ❑ RSSQL Standard 1500 Rev 6.00.02 ser# 1126000557, cat# 9356STD2300
- ❑ Microsoft Office XP SBE, GTGT6-VPQGC-77326-37FKW-DGX2M
- ❑ Microsoft SQL Server 2000 Personal Edition, SP-3a GHXDG=H74RV-JKJX4-9HTKH-QH6QY